

# HOOKER®

— FURNITURE —

## Assembly Instructions

Item Code 7228-85050 Twisted Leg Sofa Console



### Product Components:


<u>7228-85050</u>	WOODEN BASE	1pc
	WOODEN LEGS	3 PCS
	IRON NUTS	6pcs
	ALLEN KEY	1pc



### Assembly Instructions:

- Step 1 :** Place the wooden top upside down ( on a protective matt ).
- Step 2 :** Attach the wooden legs to the top as per the picture and the no.with the help of allen key.
- Step 3 : Then tighten the legs with the help of picture one by one
- Step 4 : Over turn the sofa console carefully





\*\*\* *NOW ENJOY YOUR PRODUCT* \*\*\*