




PEDESTAL BASE FOR METROPOLITAN POPCORN MACHINES




CONTENTS



1 x Back Panel



1 x Left Side Panel
(extra holes for hinges)



1 x Top Shelf
(four holes on surface)

1 x Middle Shelf
(square cutout)


1 x Bottom Shelf
(brackets for casters)



4 x Casters



1 x Door Support



1 x Door Panel



1 x Right Side Panel



1 x Magnet



1 x Door Handle



40 x Long Screws



2 x Washers



4 x Wing Nuts



12 x Short Screws




6 x Cap Nuts



4 x Bolts

1 INSTALL THE MAGNET


- Attach the **magnet** to **middle shelf** with **long screws**.



2 ATTACH SIDE PANELS

- Attach the **left and right side panels** to the **top shelf**, **middle shelf**, and **bottom shelf** with **long screws**.
- Continue to secure the **left and right side panel** with additional **long screws** from the front.

**DO NOT TIGHTEN SCREWS
UNTIL FULLY ASSEMBLED**




ASSEMBLY INSTRUCTIONS

3 ATTACH BACK PANEL


- Attach the **back panel** to the pedestal with **long screws**.

**DO NOT TIGHTEN SCREWS
UNTIL FULLY ASSEMBLED**




4 ATTACH CASTERS

- Twist the **casters** to the **bottom shelf**.



5 ATTACH THE DOOR

- Attach the **handle** to **door** with **handle support plate**, **long screws** and **washers**.
- Attach **hinges** to **left side panel** with **short screws**.
- Attach **hinges** to **door** with **short screws** and secure with **cap nuts**.



6 FINAL CHECK

- Stand the pedestal upright on a level surface/floor.
- Ensure casters are touching the floor evenly.
- Firmly tighten all screws to ensure they are secure.

7 SECURE THE POPCORN MACHINE

- Place the popcorn machine on top of the pedestal.
- Open the popcorn machine and remove the drop door and clean out tray.
- Locate the holes on the bottom of the popcorn machine and secure to the pedestal with **bolts** and **wing nuts**.

