




DESIGNED IN CALIFORNIA



— MODERN POLY ADIRONDACK CHAIR —

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

<https://westintrends.com/welcome>



QUESTIONS OR COMMENTS?

If you have questions reach out to
cs@westintrends.com

FOLLOW, SHARE, & LEARN



PRODUCT REGISTRATION

<https://westintrends.com/apps/product-registration>



ACCESSIBILITY - COMMUNITY - VALUE - SUSTAINABILITY

! CARE & MAINTENANCE

Please keep this instruction for your future reference.

- Be careful when assembly, avoid hurting the top surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



ALLEN WRENCH
(PROVIDED)



CHAIR
330 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 30 MIN.
ASSEMBLY

HARDWARE

1

BOLT
M6 x 55mm



2 PCS

2

BOLT
M6 x 50 mm



6 PCS

3

SCREW
M6.3 x 80 mm



2 PCS

4

SCREW
M6.3 x 50 mm



8 PCS

5

SCREW
M6.3 x 40 mm



1 PC

6

M6 NUT



8 PCS

7

M6 WASHER



8 PCS

8


WRENCH



1 PC

9

ALLEN
WRENCH




1 PC

PARTS

A


CHAIR SEAT



1 PC

B

REAR LEG



2 PCS

C

CUP SUPPORT




1 PC

PARTS

D

RIGHT CHAIR ARM



1 PC

E


LEFT CHAIR ARM



1 PC

F


CHAIR BACKREST



1 PC

G


RIGHT CHAIR LEG



1 PC

H

LEFT CHAIR LEG



1 PC

I


BACK RAIL



1 PC

PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this chair and learn the exact position of each parts to be assembled.



PRODUCT ASSEMBLY


1

Attach 2 pcs of **Part B Rear Leg** to **Part A Chair Seat** with 4 pcs of **Hardware #4 Screw**.




2

Attach **Part I Back Rails** between **Part B Rear Legs** with 2 pcs of **Hardware #4 Screw**.




3

Attach **Part C Cup Support** to **Part G Right Chair Leg** with 1 pc of **Hardware #5 Screw**.



4


Attach **Part G Right Chair Leg** to **Part B Rear Leg** with 3 sets of **Hardware #2 Bolt**, **#7 Washer** and **#6 Nut**.



PRODUCT ASSEMBLY

5


Attach **Part H Left Chair Leg** to **Part B Rear Leg** with 3 sets of **Hardware #2 Bolt**, **#7 Washer** and **#6 Nut**.



6

Attach **Part E Left Chair Arm** to **Part H Left Chair Leg** with 1 set of **Hardware #1 Bolt**, **#7 Washer** and **#6 Nut**.

Do the same to assemble **Part D Right Chair Arm** to **Part G Right Chair Leg**.




PRODUCT ASSEMBLY

7

Attach **Part F Chair Backrest** to **Part D Right Chair Arm** and **Part E Left Chair Arm** with 2 pcs of **Hardware #3 Screw**.


Attach **Chair Backrest** to 2 pcs of **Part B Rear Legs** with 2 pcs of **Hardware #4 Screw**.



8

Tighten all the screws when the parts are loosely attached.

Enjoy the chair now.



REGISTRATION & REFUND POLICY

<https://westintrends.com/apps/product-registration>



<https://westintrends.com/policies/refund-policy>



HAVING TROUBLE

- **Not sure how to assemble or missing pieces?**

Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - **DO NOT exceed 1500 PSI** - this will remove any debris and dirt.