


# SINGLE HEAD COMMERCIAL SECURITY FLOOD LIGHT

---

## IMPORTANT SAFETY INSTRUCTIONS AND INSTALLATION GUIDE



**READ BEFORE INSTALLATION**  
**SAVE THESE INSTRUCTIONS**



# Table of Contents

Table of Contents	2
Safety Information	2
Care and Maintenance	2
Warranty	2
Pre-Installation	3
Tools Required	3
Hardware Included	3
Installation Preparation	3
J-Box or Post Mount Installation	4
Wiring for a Standard Wall Switch	5
Wiring for 0-10V Dimmer	5
Troubleshooting	5
Operation	5

## Safety Information

For your safety, always remember to:

- ❑ Turn off the power supply at the fuse or circuit breaker box before you install the fixture.
- ❑ Ground the fixture to avoid potential electric shock and to ensure reliable starting.
- ❑ Double-check all connections to be sure they are tight and correct.
- ❑ Wear rubber soled shoes and work on a sturdy wooden ladder.
- ❑ Account for small parts and destroy packing material, as these may be hazardous to children.

This fixture is designed for use in a circuit protected by a fuse or circuit breaker. It is also designed to be installed in accordance with local electrical codes. If you are unsure about your wiring, consult a qualified electrician or local electrical inspector, and check your local electrical code.

Account for small parts and destroy packing material, as these may be hazardous to children.

**NOTICE:** All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

### Product Specifications

- 120/277 VAC, 50/60Hz, 120W max
- Suitable for wet locations
- Dimmable with 0-10V dimmers only
- Suitable for mounting within 4 ft. (1.2 m) of the ground



**WARNING: RISK OF SHOCK.** House electric current can cause painful shock or serious injury unless handled properly.



**CAUTION:** Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.



**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



**WARNING: RISK OF CUTS.** Some metal parts in the fixture may have sharp edges. To prevent cuts and scrapes, wear gloves when handling the parts.

### Dusk to Dawn Operation:

The light will turn on at dusk and remain on through the night until dawn. The light will remain off throughout the day, until dusk.

**NOTICE:** To make sure this function works properly, always keep the wall switch in the "ON" position (including daytime).

## FCC STATEMENT

### Supplier's Declaration of Conformity:

47 CFR § 2.1077 Compliance Information

**Responsible Party:** Feit Electric Company

4901 Gregg Road, Pico Rivera, CA 90660, USA

www.feit.com

**Unique Identifier:** S12FL/ADJ/3CCTLSDBZ

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

## Care and Maintenance


Periodically clean the fixture and diffuser using a mild, non-abrasive cleaner and soft cloth. When cleaning the fixture, make sure the power is turned off. Do not spray cleaner directly onto any part of the fixture or LEDs.

## Limited Warranty


This product is warranted to be free from defects in workmanship and materials for up to 5 years from date of purchase. If the product fails within the warranty period, please contact Feit Electric at info@feit.com, visit feit.com/contact-us for instructions on replacement or refund. REPLACEMENT OR REFUND IS YOUR SOLE REMEDY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IS HEREBY EXPRESSLY EXCLUDED. Some states and provinces do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

# Pre-Installation


## TOOLS REQUIRED (NOT INCLUDED)



6mm  
Allen Wrench



5/16" Phillips  
screwdriver




5/16" slotted  
screwdriver


## HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



AA



BB




CC

Part	Description	Quantity
AA	Single Head Commercial Security Flood Light	1
BB	Nut	1
CC	Wire Nuts	5

# Installation Preparation

- ☐
- The fixture must be mounted using the Swivel Knuckle into a domed cover plate (not provided) on a junction box or via a landscape post (sold separately).




## 1 Turning off the Power

- Turn the power OFF at the switch and fusebox or the circuit breaker.

## 2 Installing the Flood Light into the Weather Proof Cover or Landscape Post

- Install the fixture's swivel Knuckle extension with ½ in. thread into a weatherproof J-Box cover (sold separately) or landscape post (sold separately) for ground mount installation.



**NOTE:** Ensure the weatherproof J-Box cover and landscape post is provided with 1/2 in. threaded opening to install the fixture's swivel knuckle extension.

## 3 Connecting the Power Supply Wires


- Using the wire nuts (provided), connect the supply wires to the fixture's wires:
- See wiring diagram A or diagram B



**NOTE:** Purple and Pink wires to be used with 0-10V dimmers only (purple +10V, pink -10V). Purple (+10V) - Purple from dimmer Pink (-10V) - Pink from dimmer. See wiring diagram B.


## 4 Securing the Fixture

- Mount the fixture onto the J-Box. Please ensure to follow the weatherproof cover or landscaping post manufacture installation instructions.




## 5 Tighten the Nut and Waterproof

- Tighten the Nut (BB) on the Security Flood Light (AA) or landscape post (sold separately) for ground mount installation to secure it from moving.
- If water proof seals are not provided, to prevent water or moisture from entering the fixture between the fixture and mounting surface, waterproof silicon, caulk or gel should be applied to seal any gaps around the junction point.




**NOTE:** To adjust the angle of the fixture, loosen the Set Screw of the swivel with a 6mm allen wrench and position to a suitable angle and tighten the screw firmly.




## 7 Turning the Power On

- Turn the power ON at the wall switch, fusebox or the circuit breaker.

WIRING DIAGRAM A




WIRING DIAGRAM B



Problem	Possible Cause	Solution
LED Flood light comes on during the day.	1. Dusk-to-Dawn sensor is in a shaded area and is fooled into thinking it is nighttime. 2. Dusk-to-Dawn sensor is possibly dirty.	1. Shine a flashlight onto the light sensor. If the security light turns off, the fixture is mounted in an area that does not allow enough light to enter the sensor, relocate the fixture and try again. 2. Clean sensor with a damp soft cloth.
LED Flood light cycles ON and OFF continuously.	Dusk-to-Dawn sensor is sensing reflected light from the LED Wall Pack.	1. Ensure no reflective materials are near to the wall pack. 2. Relocate the fixture to a different location where it no longer causes reflected light.

## CCT Switch

- Select the color temperature:  
3000K – Soft White  
4000K – Bright White  
5000K – Daylight




## Wattage Switch

- Select your Wattage:  
120W  
100W  
80W

- The light settings and D2D setting are located under watertight gasket covers on the back of the fixture. To access the covers, use a 5/16" slotted or Phillips screwdriver (not included) to unscrew and remove them.

## Beam Spread Switch

- Select the beam angle spread to adjust the coverage of the light:  
7x7 (100°)  
6x6 (65°)  
5x5 (55°)



## D2D Switch

- ON Position - Light will automatically turn on at dusk and remain off during the day.
- OFF Position - Light will always stay on, regardless of time of day.

- The D2D sensor is secured under the watertight gasket cover at the bottom of the fixture. To access the cover, use a 5/16" slotted or Phillips screwdriver (not included) to unscrew and remove them.

