
INSTRUCTION MANUAL




26" Chenille Upholstered Swivel Counter Stool

(!) CARE & MAINTENANCE

Please keep this instruction for your future reference.

- Be careful when assembly, avoid hurting the painted surface.
- Clean the stool with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.



PARTS


1 PC



1 PC

PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this stool and learn the exact position of each parts to be assembled.




PRODUCT ASSEMBLY



Pick out Part B and Part C Stool Legs from package.


Remove the protection wood from the legs.



PRODUCT ASSEMBLY


2

Place **Part B** and **Part C Stool legs** as below and attach them with 1 set of **Hardware #1 Bolt, #4 Washer**.



3

Place **Part D Rail** into **Part B** and **Part C Stool legs** as shown below, attach them with 4 pcs of **Hardware #2 Bolt**.




PRODUCT ASSEMBLY




Place **Part E Swivel Disc** onto the assembled stool legs as below, swivel the top disc 45° to show the screw holes on base disc.

Attach the base disc to the assembled stool legs with 4 pcs of Hardware #1 Bolt.




5

Place the assembled stool legs as shown below, attach **Part A Stool Seat** to **Part E Top Swivel Disc** with 4 pcs **Hardware #3 Bolt**.




Attach 4 pcs of **Hardware #5 Adjustable Foot Levelers** to the assembled stool legs.



Check and tighten all the bolts again to ensure the stool is steady enough.

Try to sit down and swivel **Part A Stool Seat** to ensure it moves smoothly.

Adjust the foot leveler to ensure four feet is evenly to the ground.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.