



Item No: W-5069G

Fantasy Fields - Cracked Rose Table Lamp

WARNING

Small parts and sharp points may be present prior to assembly.

CARE INSTRUCTIONS

To clean your product, use mild soap and water on a damp cloth. Do not use window cleaners or cleaning abrasives as they will scratch the surface and could damage the protective coating.

CUSTOMER SERVICE

For questions regarding this product, or to receive replacement or missing parts, please contact customer service based on your location. Please have ready the model number and part number(s) located in this assembly instruction sheet when you contact us.

Made in China

Shade Assembly

Instructions

Use 40 Watt Type A bulb, 120v 60hz AC only.

WARNING:

This is an electrical lamp-not a toy. To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.

