

Thank you for purchasing Leick Furniture products. Contact customer service for comments or concerns.

Sheboygan,WI

920-451-4060

info@leickhome.com

(P) www.leickhome.com

Assembly Instructions, #11632 Hall Console

Parts List

Item	Parts	Description	Quantity
Α		Top Assembly	1
В		Front Legs	2
С		Right Back Leg	1
D		Left Back Leg	1
Е	Ø	Shelf	1


Hardware List

Item	Hardware	Description	Quantity
1		Allen Bolts	8
2	0	Flat Washers	8
3	G	Lock Washers	8
4		Allen Wrench	1
5	Ø	Shelf supports	4

Assembly Steps

Step 1

- 1.1 Lay the Top Assembly (A) upside-down on a soft surface.
- 1.2 Place the legs as per following sketch with stickers -Legs C and D belongs to one side pointed by the 'back' arrow sticker seen at the bottom surface of top panel.
- 1.3 Fasten the legs with (8) bolts, flat washers and lock washers using the Allen wrench. Do not tighten, leave enough clearance



Step 2

- **2.1** Position the assembled piece upright.
- 2.2 Insert all shelf supports to the holes on legs. Tilt the shelf slightly and insert one end between legs above the shelf supports first, then bring the other end up to have it rest evenly on 4 shelf supports.
- **2.3** Check to ensure all joints are properly aligned. Push the legs moderately inward while tightening all the bolts.

