



AMBITION PENCIL



- Ambition Pencils come equipped with 0.7 mm (B) lead.

1. Remove the front piece (1) from the barrel (2) by turning the front piece (1) counterclockwise.
2. Remove the plastic cap from the end of the lead holder (5).
3. Insert new Faber-Castell 0.7 mm leads into the lead holder (5). Add no more than 5 leads. If more leads are used this may cause a jam.
4. Return the cap to the lead holder (5).
5. Return the front piece (1) to the barrel (2) by turning the front piece (1) clockwise until secure.
6. Twist the cap (4) to advance the lead to begin writing.
7. To retract the lead, hold the barrel (2), turn the cap (4) and hold it in place. Push the lead back into the lead holder (5) while the cap (4) is held in place.

Refills Eraser: #188202
Lead: **0.7mm** (B) standard #122298
Other degrees of lead hardness also available (2B, HB, H, 2H)

Note The lead will NOT advance properly unless the lead holder (5) is securely fastened into the front piece (1).