


homestyles®

20 05525 0991

Bar




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


Part List




A.
Top
1 pc.



L.
Door
1 pc.



E.
Front Panel
1 pc.



F.
Front Panel
1 pc.

For assembly see instructions in carton 20 05525 0992.

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319