



LOOM BALLPOINT PEN



- LOOM Ballpoint Pens come equipped with a broad, black ballpoint refill.

1. Remove the front piece (1) from the barrel (2) by turning the barrel (2) counterclockwise.
2. Remove the empty ballpoint refill (3) from the front piece (2).
3. Insert new Faber-Castell Ballpoint Refill (3) into the front piece (1).
4. Return the front piece (1) to the barrel (2) by turning the barrel (2) clockwise.
5. Hold the front piece (1) and turn the barrel (2) clockwise to advance the ballpoint (3) and begin writing.
6. To retract the ballpoint (3) hold the front piece (1) and turn the barrel (2) counterclockwise.

REFILLS Ballpoint: #148780 Fine, Black
 #148789 Medium, Black
 #148788 Medium, Blue
 #148742 Broad, Black
 #148743 Broad, Blue
 #148794 Extra Broad, Black
 #148793 Extra Broad, Blue