

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

### Make sure to read the instructions below before assembling your double power swivel Recliner


**Step1** Attached to the top of the swivel base is the hardware bag that includes the plug transformer. Remove the parts from the bag and attach the wallplug transformer. Make sure to close the clip lock to prevent the connection from coming loose during use. Set the assembly aside to be used in step5.



**Step2** Attaching the Recliner Back: Position the KD back(A) with the KD receivers positioned over the mechanism post on the recliner body (B) as pictured below. Check to assure both sides of the mechanism post are positioned inside of the KD receivers on the back frame, push in a downward motion from the top of the back frame until a clicking sound is heard.




**Step3** Attach the lead wires found at the bottom of motion back to the lead wires at the rear of seat. The headrest leadwires are yellow to yellow. Make sure to close the clip locks to assure the connections will not come loose during use.



**Step4** Attach the outside back across the bottom rear of each seat rail with the pre attached Velcro.

**Step5** Attach the matching end from the plug transformer extension cord to the lead wire coming from the swivel base. Make sure to close the clip lock to prevent the connection from coming loose during use.

After assembly is complete your product should look as seen below.



Do Not plug the power cord into a power outlet until your recliner is fully assembled and in placed.


#### Notes:

- 1) To help prevent shock and or damage to your product only plug the power cord into a grounded outlet.
- 2) Read the operating instructions carefully before operating your power recliner.

# **Operating Instructions for The Dual Power Swivel Recliner**

Caution: Read the Important instructions below before operating your power mechanized equipment.

Do not allow children to play on or operate this power mechanized equipment.



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation.

## **Open and Close Buttons**

The control panel uses rocker switches. To operate the function you desire simply touch the end of the rocker switch with the noted function. To stop the mechanism/function in your desired position simply remove your finger from the button.

**To Close All:** To simultaneously return the headrest, recliner to their closed positions, press and hold the end of rocker switch noted as mechanism close. To stop this function at any time simply remove your finger from the button.

## **Customer Service**

If you have any questions regarding the use of this unit,or find that your unit needs service, please contact your retailer.

Product Protected By Following Patents: Patented Articulating Power Headrest US Patent: 10,736,423 Patented 360° Power Swivel US Patent: 10,376,061