



0






WARRANTY

www.speakman.com

Warranty information can be found at:



Clean wall surface. Place Mounting Base (1) onto the valve, align mounting holes, and secure with supplied

