
INSTRUCTION MANUAL




! CARE & MAINTENANCE

Please keep this instruction for your future reference.


- Be careful when assembly, avoid hurting the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.




HARDWARE




PARTS





PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this dining table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY



Place **Part A Table Top** upside down on soft surface like carpet to avoid damage. Loosely attach 1 pc of **Part B Table Leg** to **Part A Table Top** with 2 pcs of **Hardware #1 Bolt**.


Pay attention to the different heights of base holes that meets the holes in the aprons.



PRODUCT ASSEMBLY


2

Attach Part C Rail to Part B Table Leg with 1 pc of Hardware #1 Screw.



3


Loosely attach 1 pc of **Part B Table Legs** to **Part A Table Top** and **Part C Rail** with 3 pcs of **Hardware #1 Screw**.



PRODUCT ASSEMBLY




Attach 2 pcs of Part C Rails to Part B Table Legs with 2 pcs of Hardware #1 Screw.



5

Do the same to assemble the rest Part B Table Legs, Part C Rail & Part A Table Top.




PRODUCT ASSEMBLY



Tighten all the screws when all the parts are loosely attached. Turn over the table and enjoy it now.

Remark: Please remove the umbrella hole cover when you insert the umbrella.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.