


INSTRUCTION MANUAL



Kids Outdoor 5-Piece Dining Set

V1.0

TABLE OF CONTENTS

ASSEMBLY INSTRUCTIONS

Kids Outdoor 24" Dining Table 3

Kids Outdoor Dining Chair 7

INSTRUCTION MANUAL



Kids Outdoor 24" Dining Table

! NOTICE

Please keep this instruction for your future reference.

- Be careful when assembling, avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.


TOOLS REQUIRED



HARDWARE

1

SCREW
M6 x 70 mm




12 PCS

PARTS

A


TABLE TOP



1 PC

B


LEG I



2 PCS

C

LEG II



2 PCS

D


**UMBRELLA
COVER**



1 PC

PRODUCT ASSEMBLY – OVERALL VIEW

Look at following overall view of this table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Place **Part A Table Top** upside down on soft surface like carpet to avoid damage.

Attach **Part B Leg I** and **Part C Leg II** to the aprons of **Part A Table Top** as below with 6 pcs of **Hardware #1 Screw**.


Pay attention to match the holes in the aprons.



PRODUCT ASSEMBLY

2

Do the same to attach the **Part B Leg I** and **Part C Leg II** to the aprons of **Part A Table Top** with 6 pcs of **Hardware #1 Screw**.




3


Check and tighten all the bolts again to ensure the table is steady enough.

Remove the **Umbrella Cover** to assemble the umbrella pole.

Enjoy this table now.



INSTRUCTION MANUAL



Kids Outdoor Dining Chair

! NOTICE

Please keep this instruction for your future reference.

- Be careful when assembling, avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



CHAIR
300 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 20 MIN.
ASSEMBLY

HARDWARE

1

SCREW
M6 x 55mm



6 PCS

2


SCREW
M6 x 85mm



8 PCS

3

BOLT
M6 x 55mm



2 PCS

4

BOLT
M6 x 30mm




2 PCS

PARTS

A


CHAIR SEAT



1 PC

B

**CHAIR
BACKREST**



1 PC

C


FRONT LEG



2 PCS

D


REAR LEG



2 PCS

E


RAIL



1 PC

PRODUCT ASSEMBLY – OVERALL VIEW

Look at following overall view of this chair and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Attach **Part E Rail** between both pcs of **Part D Rear Legs** with 2 pcs of **Hardware #1 Screw**.

Place **Part B Chair Backrest** on flat surface, attach the combined leg (**Part D Rear Leg** + **Part E Rail**) with 2 pcs of **Hardware #3 Bolt** and 2 pcs of **Hardware #4 Bolt** as below.




PRODUCT ASSEMBLY

2

Place **Part A Chair Seat** upside down on soft surface like carpet to avoid damage.


Attach 2 pcs of **Part C Front Legs** to the aprons of **Part A Chair Seat** with 4 pcs of **Hardware #1 Screw** and 4 pcs of **Hardware #2 Screw** as below.

Pay attention to match the holes in the aprons.



3

Attach the combined part (**Part B Chair Backrest** + **Part D Rail**) to **Part A Chair Seat** with 4 pcs of **Hardware #2 Screw**.




PRODUCT ASSEMBLY

4

Check and tighten all the bolts again to ensure the chair is steady enough.

Enjoy this chair now.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.