




Patriotic Windmill

Assembly Instructions






Parts List

- A. Cap Nut
- B. Fin
- C. Wheel
- D. Top Pole
- E. Middle Pole (2)
- F. Stake Base
- G. Stake Support




1. Attach wheel (C) face-out on fin (B) by inserting threaded portion through center hole of wheel. Next, screw on cap nut (A) by turning it to the right until it is firmly tightened.



Lay assembly on the ground for the following steps.

2. Firmly attach top pole (D) by inserting the pole directly into the bottom of fin (B). Insert one of the middle poles (E) into the bottom of the top pole (D) and align the button on middle pole (E) with the hole on (D) until it clicks into place. Connect second middle pole (E) and repeat process. Then, slide the stake support (G) into the stake base (F). Then, slip the stake base (F) into the bottom of the middle pole (E) until it clicks into place. When everything is assembled, insert stake base firmly into the ground. For best results, install on a flat ground and ensure that the stake is 90 degrees vertical to the ground.



FOR DECORATIVE USE IN THE GARDEN. NOT TO BE GIVEN TO CHILDREN AS TOY.
© 2017 Exhart - Chatsworth, CA 91311. • Made in China / Fabrique en Chine. All Rights Reserved.

For help please call 1-(800) 775-5503
www.exhart.com