

Age
6+

deluxe SCRATCH ART

Introducing a full scratch art studio experience with less mess! Scratch your papers to reveal fun rainbow and foil designs. Clean up using the adorable unicorn desk vacuum!



I'm a magical mini vac!



BATTERY WARNING:

Remove the cover as shown and insert 2AA batteries following the + and - icons inside the vacuum
Remove dead or exhausted batteries
Do not mix old and new batteries
Do not mix standard (carbon zinc), alkaline, rechargeable (nickle cadmium) or lithium batteries
Do not recharge non-rechargeable batteries
Dispose of batteries safely, following guidelines for your area
Clean the battery contacts and also those of the device prior to battery installation

Need Help?
Call: 800-311-8684 e-mail: consumer@fabercastell.com
Chat or view FAQs & INFO online: creativityforkids.com



CREATIVITYFORKIDS.COM

Deluxe Scratch Art #651700
© Faber-Castell USA, Inc.
Cleveland, Ohio 44131
www.fabercastell.com

Designed in USA
Made in China
Conforms to ASTM D-4236
Non-toxic Safe for Children

Ask an adult for assistance. To use your unicorn vacuum you'll need to add 2 AA batteries (not included).

Holding the base, squeeze the top sides and pull up to pop the top off as shown.



STEP 1



STEP 2

Add 2 AA batteries as shown in the machine.

To clean the crumbs from your vacuum, be sure your vacuum is turned off. Hold the top and the base and turn clockwise. Pull the base down to remove.



STEP 4



Dump the crumbs and place the base back on by turning it counterclockwise to lock it on.



STEP 3

Pop the top on by lining up the back near the power button first, then pushing the front down onto the base.

Press the power button to turn the vacuum on and off.



With our boards, you can scratch away, but the designs will stay!

Add your own artwork within the frames!

