


Assembly Guide



Bush
FURNITURE




**If you're having any difficulty during assembly
of this product, don't hesitate to call us at
1-800-950-4782.**

Our customer service experts are trained to provide step-by-step instruction and can easily replace any missing or damaged parts.

**Representatives are available Monday-Friday
from 8:30 a.m. to 7:30 p.m. (ET)**

60W Storage Cabinet



Lot Code #

Part Number A209438

Keep manual for future reference.

For best results, keep these tips in mind:

- ① We know you want to finish this assembly as quickly as possible, but trust us: you'll have a better experience if you take it one step at a time.
- ② Give yourself some room to work near where you want the fully assembled product.
- ③ If your floor isn't carpeted, assemble this product on the empty carton to avoid scratching.
- ④ Do you have a friend who owes you a favor? Some steps may go a little easier with a second set of hands.

DOs

- ✓ Use a #2 Phillips head screwdriver (or other handheld tools as indicated)
- ✓ Wear safety glasses at all times during assembly
- ✓ Carefully follow the instructions in this guide and complete all steps in order
- ✓ Give us a call if you're having trouble with a particularly tricky step

DON'Ts

- ✗ We know power tools are quick and easy, but you shouldn't use them when assembling this product (unless otherwise specified)
- ✗ Never move your furniture with items inside or resting on the surface
- ✗ Do not attempt to use this product before all steps have been completed

**Watch assembly videos right on your phone or computer!**

Some steps include QR codes that link to helpful videos. Watch out for the icon below! Simply open up your smartphone camera to scan the code.

(Users of older smartphones may need to install a QR Reader.)

SCAN HERE**FOR VIDEOS**

Or visit <https://bushfurniture.com/help-faq/#assembling>

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Warning	Do	Don't	Why it's important
Serious injury or death may occur.	• Only place flat screen TVs on this product • Assemble following all instructions using all indicated parts and hardware provided. • For use with televisions weighing 80 lbs (36.3 kg) or less and having a diagonal screen size of 75 inches (1905mm) or less • Install every indicated nail and/or screw. • Verify Furniture is stable on it's own. • Place heaviest items in the lower drawers or shelves. • Always install tipover restraint hardware provided. • Remove items that might tempt kids to climb, such as toys and remote controls from the top and upper shelves of furniture.	• Do not move unit when loaded. • Do not exceed the maximum load limits stated in the instructions. • Do not allow children to stand, climb, or hand on furniture.	Improper assembly, use or loading can lead to product instability, tip-over or collapse.

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Advertencia	Hacer	No	Por qué es importante
Se pueden producir lesiones graves o la muerte.	• Solo coloque televisores de pantalla plana en este producto. • Ensamble siguiendo todas las instrucciones utilizando todas las piezas y hardware indicados provistos. • Para usar con televisores que pesen 80 lbs (36.3 kg) o menos y que tengan un tamaño de pantalla diagonal de 75 pulgadas (1905 mm) o menos. • Instale cada clavo y / o tornillo indicado. • Verifique que los muebles sean estables por sí mismos. • Coloque los artículos más pesados en los cajones o estantes inferiores. • Siempre instale el hardware de restricción tipover proporcionado. • Retire los artículos que puedan tentar a los niños a trepar, como juguetes y controles remotos de los estantes superiores y superiores de los muebles.	• No mueva la unidad cuando esté cargada. • No exceda los límites máximos de carga establecidos en las instrucciones. • No permita que los niños se paren, trepen o toquen los muebles.	El ensamblaje, uso o carga inadecuados pueden provocar inestabilidad del producto, vuelco o colapso.

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Avertissement	Faire	Ne le fais pas	Pourquoi c'est important
Des blessures graves ou la mort peuvent survenir.	- Placez uniquement des téléviseurs à écran plat sur ce produit. - Assemblez en suivant toutes les instructions en utilisant toutes les pièces et le matériel indiqués fournis. - Para usar con televisores que pesen 80 lbs (36.3 kg) o menos y que tengan un tamaño de pantalla diagonal de 75 pulgadas (1905 mm) o menos. - Installez tous les clous et /ou vis indiqués. - Vérifiez que les meubles sont stables par eux-mêmes. - Placez les articles les plus lourds dans les tiroirs ou les étagères inférieurs. - Installez toujours le matériel de retenue de renversement fourni. - Retirez les éléments qui pourraient inciter les enfants à grimper, tels que les jouets et les télécommandes des étagères supérieure et supérieure des meubles.	- Ne déplacez pas l'unité lorsqu'elle est chargée. - Ne dépassez pas les limites de charge maximales indiquées dans les instructions. - Ne laissez pas les enfants se tenir debout, grimper ou mettre la main sur des meubles.	Un assemblage, une utilisation ou un chargement incorrects peuvent entraîner une instabilité du produit, un renversement ou un effondrement.

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Caution	Do	Don't	Why it's important
Injury may occur.	• Handle glass carefully during assembly. • Use proper eye and hand protection.	• Do not exceed maximum load limits stated in the instructions.	• Improper handling or loading may result in glass breakage.

Atención	Hacer	No	Por qué es importante
Se pueden producir lesiones.	• Manipule el vidrio con cuidado durante el montaje. • Use protección adecuada para los ojos y las manos.	• No exceda los límites máximos de carga establecidos en las instrucciones.	• La manipulación o carga inadecuadas pueden provocar la rotura del vidrio.

Attention	Faire	Ne le fais pas	Pourquoi c'est important
Des blessures peuvent survenir.	• Manipulez le verre avec précaution lors du montage. • Utilisez une protection appropriée pour les yeux et les mains.	• Ne dépassez pas les limites de charge maximale indiquées dans les instructions.	• Une manipulation ou un chargement incorrect peut entraîner la rupture du verre.

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.



WARNING

For use with televisions weighing 80 lbs (36.3kg) or less and having a diagonal screen size of 75 inches (1905 mm) or less

Use with heavier or larger televisions may result in instability causing tip-over resulting in death or serious injury.



ADVERTENCIA

Para usar con televisores que pesen 80 libras (36.3 kg) o menos y que tengan un tamaño de pantalla diagonal de 75 pulgadas (1905 mm) o menos.

El uso con televisores más pesados o más grandes puede provocar inestabilidad, volcarse y provocar lesiones graves o la muerte.





AVERTISSEMENT

Pour les téléviseurs pesant 80 (36,3 kg) ou moins et ayant une diagonale d'écran de 75 pouces (1905 mm) ou moins.

L'utilisation avec des téléviseurs plus lourds ou plus grands peut entraîner de l'instabilité et causer le basculement, entraînant la mort ou des blessures graves.

C207087A


Bush Industries, Inc.
One Mason Drive, P.O. Box 460
Jamestown, NY 14701



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Fasteners are shown actual size.


H181468



KD Cam

[34]


H72988



KD Bolt


[34]

H38169


Wood Dowel
8 x 30mm

[28]

H146988



#12 x 1/2"

[8]


H160460



M4 x 22mm

[12]


H26053



#10 x 1-1/4"

[12]


H208081



#8 x 5/8"

[16]

H192100



#8 x 1/2"

[8]

H34174



#3 x 3/4"

[47]


H195734



6.3x13mm ZINC

[8]

H204610



#6 x 1/2"

[8]

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Get to know your Hardware

A209438

Hardware not to scale.


H149989



Bumper

[4]


H170612



Mounting Plate

[4]


H170611



Hinge Arm

[4]


H100445



Drawer Bracket

[4]


H211142



Hinge with Mounting Plate

[4]


H209491



Handle

[6]

H158707



Shelf Pin

[8]


H200203



Cover Cap

[10]

Q211120



12" Slide


[2]

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Hardware not to scale.


TIP OVER RESTRAINT HARDWARE


Q203419

H181434  [1]
#10x2"

H107572  [1]
#8x1-1/2"

H181412  [2]
Connecting Plate

H181419  [1]
Toggle Bolt

H181411  [1]
Nylon Cable Tie


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 1

Prepare Doors

A209438


H170611



[2]

Hinge


H208081



[8]

#8 x 5/8"


H209491



[2]


Handle

H160460



[4]

M4 x 22mm



CAUTION



Risk of breaking glass. Handle glass carefully during assembly. Use eye and hand protection. Improper handling can result in cuts or lacerations.

Riesgo de romper el vidrio. Maneje el vidrio con cuidado al ensamblar esta unidad. Use protección para sus ojos y sus manos. El manejo inapropiado del vidrio puede causarle cortaduras o laceraciones.

Risque de bris de verre. Faites attention lors de la manipulation du verre pendant l'assemblage. Utilisez des protections pour les yeux et les mains. Une mauvaise manipulation peut provoquer des coupures ou des lacerations.


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 2

Prepare Doors

A209438


H211142



[4]

Hinge with Mounting Plate


H208081



[8]

#8 x 5/8"


H209491



[2]



Handle

H160460



[4]

M4 x 22mm



CAUTION



Risk of breaking glass. Handle glass carefully during assembly. Use eye and hand protection. Improper handling can result in cuts or lacerations.

Riesgo de romper el vidrio. Maneje el vidrio con cuidado al ensamblar esta unidad. Use protección para sus ojos y sus manos. El manejo inapropiado del vidrio puede causarle cortaduras o laceraciones.

Risque de bris de verre. Faites attention lors de la manipulation du verre pendant l'assemblage. Utilisez des protections pour les yeux et les mains. Une mauvaise manipulation peut provoquer des coupures ou des lacerations.


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 3

Prepare Panels

A209438


H100445



[4]

Drawer Bracket


H146988



[8]


#12 x 1/2"

H72988



[2]

KD Bolt



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 4

Prepare Panels



A209438

H38169




[2]

Wood Dowel
8 x 30mm



Safety glasses
Gafas de seguridad
Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 5

Assemble Panels


A209438

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468




[1]

KD Cam




H204610



[4]

#6 x 1/2"




L


F

P

Q



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 7

Assemble Panels


A209438

H26053



[6]

#10 x 1-1/4"



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 8

Assemble Panels


A209438

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468




[1]

KD Cam




H204610



[4]

#6 x 1/2"




L


F

P

S



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 10

Assemble Panels



A209438

H26053



[6]

#10 x 1-1/4"



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:




How to Separate
and Install Drawer
Slides

Slides Must Be Separated Before Assembly. After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 12

Install Slide Runners


A209438

Scan QR Code to
Watch Video on:




How to Separate and Install Drawer Slides

Q211120



12" Slide Runner

H192100




[4]

#8 x 1/2"

[1]


H160460



[2]


M4 x 22mm

H209491



[1]

Handle



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 13

Install Slide Runners


A209438

Scan QR Code to
Watch Video on:




How to Separate
and Install Drawer
Slides

Q211120




12" Slide Runner


H192100 [4]
#8 x 1/2"




H160460 [2]
M4 x 22mm



H209491 [1]



Handle




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 14

Prepare Panel



A209438

H72988



[12]

KD Bolt




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 15

Prepare Panels

A209438


H72988



[4]


KD Bolt

H38169




[10]

Wood Dowel
8 x 30mm



Safety glasses
Gafas de seguridad
Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 16

Assemble Panels


A209438

Scan QR Code to
Watch Video on:






How to Tighten
KD Cams

H181468



KD Cam

[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 17

Assemble Panels


A209438

Scan QR Code to
Watch Video on:





How to Tighten
KD Cams

H181468




KD Cam

[2]



Team Lift



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 18

Assemble Panels


A209438

Scan QR Code to
Watch Video on:





How to Tighten
KD Cams

H181468




KD Cam

[12]



Team Lift




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 19

Prepare Panel

A209438





H72988



[6]

KD Bolt




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 20

Prepare Panels

A209438

H170612



[4]

Mounting Plate


H38169



[8]


Wood Dowel
8 x 30mm

H72988



[2]

KD Bolt



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 21




Prepare Panels

A209438

Scan QR Code to
Watch Video on:



How to Separate
and Install Drawer
Slides



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 22





Prepare Panel

A209438


Scan QR Code to
Watch Video on:



How to Separate
and Install Drawer
Slides



Safety glasses
Gafas de seguridad
Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 23

Prepare Panel


A209438

Scan QR Code to
Watch Video on:



How to Separate
and Install Drawer
Slides

Q211120



12" Slide Mount


[1] H195734



[2]

6.3x13mm ZINC




H72988



[1]

KD Bolt

Flip D part over
Voltar D parte sobre
Retourner la partie D




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 24

Prepare Panels


A209438

H38169




[4]

Wood Dowel
8 x 30mm



Safety glasses
Gafas de seguridad
Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 25


Assemble Panels

A209438


Scan QR Code to
Watch Video on:



How to Tighten
KD Cams




H181468



KD Cam

[2]




H200203



Cover Cap

[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 26


Assemble Panels

A209438


Scan QR Code to
Watch Video on:



How to Tighten
KD Cams




H181468



KD Cam

[2]




H200203



Cover Cap

[2]

Finished edge
Borde terminado
Côté fini



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 27


Assemble Panels

A209438


Scan QR Code to
Watch Video on:



How to Tighten
KD Cams




H181468



KD Cam

[6]




H200203



Cover Cap

[6]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 28

Prepare Panel



A209438

H72988



[6]

KD Bolt



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 29

Assemble Panels


A209438

Scan QR Code to
Watch Video on:






How to Tighten
KD Cams

H181468



KD Cam

[6]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 30

Attach Back Panel



A209438



H34174 [47]
#3 x 3/4"



Safety glasses
Gafas de seguridad
Lunettes de protection



If ventilation is required, carefully remove punch outs in back panel.

Si se requiere ventilació, retire con cuidado los punzones en el panel posterior

Si une ventilation est néessaire, retirer soigneusement les poinçons dans le panneau arrière.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Secure unit to the wall with a tip-over restraint.



Unidad de seguro a la pared con un sistema de retención de un vuelco.

Fixer l'unité au mur avec un dispositif de retenue renversement.

1. Place unit in desired location.
2. Locate wall stud nearest unit center. **FIG A**
3. On wall, mark center of stud location 1" below top of unit. **FIG A**
4. If a wall stud cannot be located mark hollow wall at unit center. **FIG A**
5. On back of unit, mark corresponding location 3/8" below top of unit. **FIG B**


1. Coloque la unidad en el lugar deseado.
2. Localice pie derecho de pared centro de unidad más próxima.
3. En la pared del, marque el centro de la ubicación del montante 1 "abajo la parte superior de la unidad.
4. Si un poste de la pared no se puede localizar marcar pared hueca en el centro de la unidad.
5. En el dorso de la unidad, marque la ubicación 3/8 correspondiente abajo la parte superior de la unidad.

1. Placez l'unité à l'endroit désiré.
2. Localiser centre d'unité la plus proche de la paroi Stud.
3. Sur le mur, centre de emplacement du montant 1 "ci-dessous dessus de l'appareil de la marque.
4. Si un montant de mur ne peut pas être situé marquer mur creux au centre de l'unité.
5. Le dos de l'appareil, marquer l'emplacement 3/8 correspondant ci-dessous dessus de l'appareil.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

WALL STUD ATTACHMENT




Drill 1/8" hole 2" deep at mark on wall.

Taladro 1/8 "agujero 2" de profundidad en la marca en la pared.

Percer 1/8 "trou de 2" de profondeur à la marque sur le mur.


H181434



[1]


#10x2"

H181412




[1]

Connecting Plate



HOLLOW WALL ATTACHMENT




Drill 1/2" hole 1" deep at mark on wall.

Taladro 1/2 "agujero 1" de profundidad en la marca en la pared.

Percer 1/2 "trou de 1" de profondeur à la marque sur le mur.


H181419



[1]


Toggle Bolt

H181412



[1]

Connecting Plate




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 33

Wall Attachment

A209438


H107572



[1]


#8x1-1/2"

H181412



[1]



Connecting Plate



Drill 1/8" hole 1-1/4" deep at mark on unit.

Taladro 1/8 "agujero de 1-1/4" de profundidad en la marca de la unidad.





Percer 1/8 "trou 1-1/4" de profondeur à la marque sur l'unité.



H181411

[1]

Nylon Cable Tie



Pull to verify lock

Tire para verificar cerradura

Tirez pour vérifier serrure

Use replacement cable tie with minimum breaking strength of 120lbs.

Utilice reemplazo empaque Cable con resistencia a la rotura mínima de 120 libras.

Utilisez remplacement Attache de câble avec une force de rupture minimale de 120 lbs.


Have an assembly question or need a replacement part? Just call

1-800-950-4782, we are here to help.


STEP 34

Assemble Panels

A209438




H149989



Bumper


[4]

H158707



Shelf Pin

[8]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 35



Attach Doors

A209438

Scan QR Code to
Watch Video on:



How to Adjust
Door Hinges



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 36

Attach Door




A209438

Scan QR Code to
Watch Video on:



How to Adjust
Door Hinges

Team Lift



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 37

Attach Door





A209438

Scan QR Code to
Watch Video on:



How to Adjust
Door Hinges

Team Lift



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 38


Install Drawers

A209438

Scan QR Code to
Watch Video on:



How to Separate
and Install Drawer
Slides









Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:



How to Adjust
Drawer Fronts

DRAWER FRONT VIEW



REQUIRED TOOL: PHILLIPS SCREWDRIVER

HERRAMIENTA REQUERIDA: DESTORNILLADOR PHILLIPS
OUTIL REQUIS: TOURNEVIS CRUCIFORME



1. LOOSEN SCREWS.
2. ADJUST DRAWER FRONTS.
3. TIGHTEN SCREWS.

1. Afloje los tornillos
2. Ajustar frentes de cajón
3. Apriete los tornillos

1. Desserrer les vis
2. Ajuster les façades des tiroirs
3. Serrer les vis

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:



How to Clean
the Surface

Gently clean surfaces with
a damp sponge eraser.

MAXIMUM TELEVISION WIDTH: 75 INCHES
(1905 MM)

ANCHO DE LA TELEVISIÓN MÁXIMA: 75
PULGADAS
(1905 MM)


LARGEUR DE TÉLÉVISION MAXIMALE: 75
POUCES
(1905 MM)

MAXIMUM WEIGHT: 80 LBS (36.3 KG)

PESO MÁXIMO: 80 LIBRAS (36.3 KILOGRAMO)
POIDS MAXIMUM: 80 LIVRES (36.3 KILOGRAMME)

MAXIMUM WEIGHT: 30 LBS (13.61 KG)

PESO MÁXIMO: 30 LIBRAS (13.61 KILOGRAMO)
POIDS MAXIMUM: 30 LIVRES (13.61 KILOGRAMME)



MAXIMUM WEIGHT: 50 LBS (22.68 KG)

PESO MÁXIMO: 50 LIBRAS 22.68 KILOGRAMO)
POIDS MAXIMUM: 50 LIVRES (22.68 KILOGRAMME)

WARNING - Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child.

WARNING - Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto a child.

ADVERTENCIA - Pueden ocurrir lesiones graves o la muerte cuando los niños se suben a los muebles del equipo de audio y / o video. Un control remoto o juguetes colocados sobre el mueble pueden alentar al niño a trepar sobre el mueble y, como resultado, el mueble puede volcarse sobre el niño.

ADVERTENCIA: reubicar el equipo de audio y / o video en muebles que no estén diseñados específicamente para soportar equipos de audio y / o video puede resultar en la muerte o lesiones graves debido a que el mueble se derrumba o se voltea hacia un niño.

AVERTISSEMENT - La mort ou des blessures graves peuvent survenir lorsque des enfants grimpent sur les meubles d'un équipement audio et / ou vidéo. Une télécommande ou des jouets placés sur le meuble peuvent encourager un enfant à grimper sur le meuble et, par conséquent, le mobilier peut basculer sur l'enfant.

AVERTISSEMENT - Le déplacement de l'équipement audio et / ou vidéo sur un meuble non spécifiquement conçu pour supporter un équipement audio et / ou vidéo peut entraîner la mort ou des blessures graves en raison de l'effondrement du meuble ou du retournement sur un enfant.

**Congratulations! You are all done. If you
have any questions or concerns, please call.**

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

LEV160LW

A	[1]	S211003	M	[2]	W211011
B	[1]	W211004	N	[2]	W211012
C	[1]	W211005	O	[1]	S211013
D	[1]	W211006	P	[2]	W211014
E	[2]	W211007	Q	[1]	W211015
F	[2]	W211008	R	[1]	W211016
G	[1]	S211009	S	[1]	W211017
H	[1]	W211070	T	[1]	W211018
J	[2]	S210984	U	[1]	W211019
K	[1]	W211072	V	[2]	S211020
L	[2]	W211010	W	[2]	W211021

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

WARRANTY INFORMATION/INFORMATIONS POUR LA GARANTIE/INFORMACIÓN DE GARANTÍA

BUSH FURNITURE'S WRITTEN WARRANTY TO YOU

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton. To receive replacement or missing parts under this warranty, call our Consumer Service Department TOLL-FREE at 1-800-950-4782. Please have the Model, Part, and Lot Numbers found in the instruction manual available for your reference. You will also need your sales receipt or other proof of purchase. Replacement part(s) will be shipped to you at no charge with Bush Industries assuming all shipping and handling charges.

This Bush Furniture product is warranted to the original purchaser at the time of purchase and for a period of one year thereafter.

We warrant to you, the original purchaser, that our furniture and all its parts and components are free of defects in material or workmanship. "Defects," as used in this warranty, is defined as any imperfection which impairs the use of the furniture product.

Our warranty is expressly limited to the replacement of furniture parts and components. For one year after the date of purchase, Bush will replace any parts that are defective in material or workmanship.

This warranty applies under conditions of normal use. Our Bush Furniture products are not intended for outdoor use. This warranty does not cover:

- 1) defects caused by improper assembly or disassembly;
 - 2) defects occurring after purchase due to product modification, intentional damage, accident, misuse, abuse, negligence or exposure to the elements; and
 - 3) labor or assembly costs.
- 4) batteries are not included.

IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, SHALL NOT EXTEND BEYOND THE DURATION OF THE WRITTEN WARRANTY STATED ABOVE, AND IN NO EVENT SHALL BUSH BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM USE OF THE PRODUCT. Some states do not allow a limitation on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights that may vary from state to state.

VOTRE GARANTIE BUSH FURNITURE

Afin de vous assister rapidement, veuillez inspecter votre mobilier en détail immédiatement après l'ouverture du carton en cas de pièces manquantes ou défectueuses. Pour recevoir une pièce de rechange ou manquante couverte par cette garantie, appelez notre département de service clientèle GRATUITEMENT au 1-800-950-4782. Veuillez tenir à disposition les numéros de modèle, de pièce et de lot qui se trouvent dans le manuel d'instruction pour votre référence. Vous aurez également besoin de votre reçu ou d'une autre preuve d'achat. La (les) pièce(s) de rechange vous sera (seront) envoyée(s) sans frais, Bush Industries se chargeant de tous les frais d'expédition.

Tout le produit Bush Furniture est garanti à l'acheteur original à partir de la date d'achat pour une période d'un an.

Nous vous garantissons, à vous l'acheteur original, que notre mobilier et toutes ses pièces et composants sont sans défaut de matériau ou de fabrication. Le terme "défauts" utilisé dans cette garantie, est défini comme étant toutes les imperfections qui compromettent l'utilisation du meuble.

Notre garantie est expressément limitée au remplacement des pièces et des composants du mobilier. Pendant un an après la date d'achat, Bush remplacera toute pièce défectueuse dans le matériau ou sa fabrication.

Cette garantie d'applique sous des conditions d'utilisation normale. Nos produits ne sont pas destinés à être utilisés en plein air. Cette garantie ne couvre pas: 1) les défauts causés par un mauvais assemblage ou démontage, 2) les défauts ayant lieu après l'achat et dus à la modification du produit, des dommages intentionnels, des accidents, une mauvaise utilisation, un mauvais traitement, la négligence ou l'exposition aux éléments, et 3) les frais de main d'œuvre ou d'assemblage. 4) les piles ne sont pas incluses.

LES GARANTIES TACITES, Y COMPRIS LA GARANTIE DE QUALITE MARCHANDE, NE S'ETENDRONT PAS AU-DELA DE LA DUREE ECRITE CITEE CI-DESSUS, ET BUSH NE SERA EN AUCUN CAS RESPONSABLE DES DOMMAGES ACCESSOIRES OU INDIRECTS RESULTANT DE L'UTILISATION DU PRODUIT. Certains états ne permettent pas d'appliquer une limite à la durée de la garantie tacite, ni une exclusion ou limitation des dommages accessoires ou indirects; dans ce cas les limitations ou exclusion ci-dessus peuvent ne pas s'appliquer à vous.

Cette garantie vous donne des droits légaux spécifiques. Il se peut que vous ayez également d'autres droits qui peuvent varier d'un état à l'autre.

GARANTIA ESCRITA DE BUSH FURNITURE PARA USTED

Para brindarle asistencia oportuna, por favor, verifique detalladamente que a su mueble no le falte o tenga piezas defectuosas inmediatamente después de abrir la caja. Para recibir un reemplazo o la parte faltante bajo esta garantía, llame a nuestro Departamento de Servicio al Consumidor GRATIS al 1-800-950-4782. Sírvase traer los números de modelo, parte y lote que se encuentran en el manual de instrucciones disponible para su referencia. Además, necesitará el recibo de su compra u otra prueba de compra. La(s) pieza(s) de reemplazo le será(n) enviada(s) sin recargo por Bush Industries asumiendo los gastos de envío y manipuleo.

Todo mueble de Bush Furniture es garantizado al comprador original al momento de la compra y por un periodo de uno año en adelante.

Le garantizamos a usted, el comprador original, que nuestros muebles sus partes y componentes están libres de defectos en materiales o trabajo. "Defectos", según se usa en esta garantía, se define como una imperfección que perjudica el uso del producto mobiliario.

Nuestra garantía se limita expresamente al reemplazo de partes y componentes mobiliarios. Durante uno año después de la fecha de compra, Bush reemplazará cualquier parte defectuosa en material o trabajo.

Esta garantía se aplica bajo condiciones de uso normal. Nuestros productos de Bush Furniture no son para uso en exteriores. Esta garantía no cubre: 1) defectos causados por un ensamblaje o desensamblaje inadecuado; 2) defectos que ocurran después de la compra debido a modificación del producto, daño intencional, accidente, mal uso, abuso, negligencia o exposición a los elementos; y 3) costos de trabajo o ensamblaje. 4) las baterías no están incluidas.

LAS GARANTÍAS IMPLICADAS, INCLUYENDO LA GARANTÍA DE COMERCIABILIDAD, NO SE EXTENDERÁN MÁS ALLÁ DE LA DURACIÓN DE LA GARANTÍA ESCRITA MENCIONADA, Y EN NINGÚN CASO BUSH SERÁ RESPONSABLE POR DAÑOS INCIDENTALES O CONSIGUIENTES COMO RESULTADO DEL USO DEL PRODUCTO. Algunos estados no permiten una limitación sobre el tiempo de duración de la garantía implicada o la exclusión o limitación de daños incidentales o consiguientes, de manera que la limitación y exclusión mencionadas pueden no aplicarse para usted.

Esta garantía le otorga derechos legales específicos. Puede también tener otros derechos que pueden variar según los estados.

1-Year
Manufacturer's
Warranty

Register your product online:

Scan the QR Code or go to
<https://bushfurniture.com/activate-warranty/>



Assembly tips & how to videos:

Scan the QR Code to access our video guides
<https://bushfurniture.com/help-faq/#assembling>

