



Purchase Date: ____ / ____ / ____ Order/Customer Reference Number: _____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

EGG CHAIR FURNITURE COVER

The life and appearance of your cover greatly depend upon how you care for your cover.

Preserve the life of a cover by reading this guide and following the recommended care.

Save this guide and your order information for your records.

USE & CARE

- ▶ Do not drag or yank the cover across abrasive surfaces, such as cement, or over sharp corners when installing or removing. If furniture has sharp corners or edges, place foam or rubber over the sharp edge to reduce the risk of puncture or abrasion to the cover.
- ▶ Ensure the cover is fitted appropriately to prevent wind whipping and/or water accumulation. Standing water and wind whipping will weaken the fabric.
- ▶ All fabrics will eventually fade and degrade from sun exposure. Avoid using the cover in locations with extended periods of full-sun exposure.
- ▶ Avoid using the cover near trees, shrubbery, vines, etc., as many contain acids that may deteriorate or stain the cover.
- ▶ Keeping the cover clean is the best way to prevent mildew growth.

CLEANING



HAND WASH ONLY



LINE DRY



DO NOT USE BLEACH



DO NOT TUMBLE DRY



DO NOT DRY CLEAN



DO NOT IRON

- ▶ Do not use abrasive cleaners or materials to clean the cover.
- ▶ Vacuum or gently brush dirt and debris from the cover.
- ▶ Hand-wash with cold water, mild soap, and a soft cloth. For stains, a soft-bristle brush may be used.
- ▶ Thoroughly rinse soap residue from the cover. The residue will attract and hold dirt, which can promote mildew growth.
- ▶ Allow the cover to thoroughly air dry before using or storing it. DO NOT PLACE IN A DRYER; high heat will destroy the fabric.

STORAGE

- ▶ Ensure the cover is dry before storing it. Storing the cover wet can promote mildew growth that can degrade the fabric.
- ▶ Folding the cover along existing creases will help retain the waterproof coating — air dry before folding.

⚠ WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Any modification to the product or failure to follow recommended care will void the product warranty.