



**ZEBCO**

**ROAM SPINNING**

## ZEBCO ROAM20 Spinning Reel Part List

Key #	QTY	Description	ROAMSF20 Part No.	Key #	QTY	Description	ROAMSF20 Part No.
1	1	Drag Knob Unit	HAK432-05	20	1	Cam	HAK031-01
2	1	Spool Kit Include	HAK421-01	21	2	Pinion Ball Bearing Retainer Screw	HAK061-01
2A	1	Retaining Ring	HAK038-01	22	1	Pinion Ball Bearing Retainer	HAK060-01
2B	2	Drag Washer "D"	HAK080-01	23	1	Pinion Ball Bearing	UK028-06
2C	3	Drag Washer "B"	HAK033-01	24	1	Pinion Ball Bearing Holder	HAK078-01
2D	1	Drag Washer "A"	HAK081-01	25	1	Clutch	HAK463-01
2E	1	Bushing	HAK058-01	26	1	Pinion	HAK011-01
2F	1	Spool Assembly	HAK321-01	27	1	A/R Switch Shaft	HAK090-01
3	1	Spool Adjust Washer	HAK030-01	28	1	Leaf Spring	HAK089-01
4	1	Spool Click Gear	HAK037-01	29	1	A/R Lever	HAK059-01
5	1	Rotor Nut	HAK006-01	30	1	Handle Screw Cap	HAK054-01
6	1	Rotor Nut Screw	HAK094-01	31	1	Handle Screw Cap Washer	HAK132-01
7	1	Main Shaft	HAK015-01	32	1	Body Assembly	HAK301-05
8	1	Bail Holder	HAK017-01	33	1	Rear Cap	HAK250-01
9	2	Arm Lever Screw	HAK042-01	34	1	Rear Cap Screw	HAK050-01
10	1	Rotor	HAK009-01	35	1	O/S Gear	HAK053-01
11	1	Line Roller Screw	HAK108-01	36	1	Slider	HAK025-01
12	1	Arm Lever	HAK007-01	37	1	Main Shaft Screw	HAK100-01
13	1	Line Roller	HAK004-01	38	1	Drive Gear Ball Bearing(Body)	CH027-06
14	1	Line Roller Ball Bearing	CT157-07	39	1	Drive Gear	HAK012-01
15	1	Bail Wire Assembly	HAK347-01	40	1	Drive Gear Adjust Washer	AAA110-01
16	1	Rotor Cover Screw	HAK077-01	41	1	Drive Gear Ball Bearing(Side Cover)	HAK028-01
17	1	Rotor Cover	HAK087-01	42	1	Side Cover Assembly	HAK323-05
18	1	Kick Lever	HAK019-01	43	3	Side Cover Screw	HAK057-01
19	1	Coil Spring	HAK022-01	44	1	Handle Assembly, 1-pc.	HAK318-01

MODEL INTRODUCED : 2020

BASIC COLORS : Black / White/ Seafoam

EFFECTIVE DATE OF PARTS LIST / DIAGRAM : SEP 2020

DISCONTINUED : N / A

