

KINGSTON

REPAIR AND MAINTENANCE
OF BUSHING

THE MODEL



REPAIRING

1. REMOVE THE BUSHING FROM THE MACHINE



WARNING: DO NOT USE A SHARP TOOL TO REMOVE THE BUSHING FROM THE MACHINE. USE ONLY THE TOOL PROVIDED.