


homestyles®

88 5092 941

Kitchen Island




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List




A.
Top
1 pc.



F.
Foot
4 pcs.

Hardware List



Small
Hex Wrench
1 pc.

Hex Wrench
1 pc.



Flat Washer
4 pcs. (+1 extra)



Adjustable Pin
4 pcs. (+2 extra)



Cam Lock
4 pcs. (+2 extra)



Pull Handle
6 pcs.



M6x35
Head Cap Bolt
16 pcs. (+1 extra)



M6x50
Head Cap Bolt (long)
4 pcs. (+1 extra)



Spring Washer
4 pcs. (+1 extra)



Cam Lock Screw
4 pcs. (+1 extra)



M4x20
Machine Screw
6 pcs.

For assembly see instructions in carton 88 5092 942.

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319