



STAINLESS STEEL CHARCOAL BASKET

Review all information before using this product. Save this manual for future reference.



This charcoal basket is designed for use with a Sunnydaze Kamado Grill. Before use, ensure the basket properly fits within your grill and will remain stable during use.



BENEFITS

BETTER/MORE EVEN AIRFLOW

The basket design allows for airflow from above, all sides, and underneath, allowing the smoke and heat to flow more easily within the smoker/grill.

INDIRECT COOKING METHOD

When the removable divider is in place, charcoal can be kept to one side, allowing the versatility of direct heat on one side of the smoker/grill and indirect heat on the other.

EASIER CLEANUP

When done cooking, simply shake the basket to remove excess ashes. Any leftover charcoal can remain in the basket for later use.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

CARE & MAINTENANCE

SAFE USE: Only use with a compatible smoker/grill that is on a flat, level surface. Grill not included.

Cooking accessories become hot when in use. To avoid burns, always use fire-resistant gloves and long-handled tools when cooking. Never allow bare skin to touch hot surfaces, if you feel heat when your hand is close to the metal, it is too hot to move. Do not remove the charcoal basket until it is completely cool.

Extreme caution is necessary when using near children, pets or infirm persons.

NO PLASTIC: Never use any plastic materials in or near the charcoal basket. The emissions from burning plastic are toxic. Additionally, plastic residue is very difficult to remove and could cause permanent damage to many parts of the unit.

EXPOSURE & MAINTENANCE: Exposure to high-intensity heat causes stainless steel to patina. As with any outdoor steel product, periodic maintenance is required to maintain integrity and appearance.

CLEANING: Never use acid-based cleaners or abrasive materials to clean stainless steel, and never clean stainless steel against the grain.

Ensure components are completely cool before cleaning.

Wash components with warm water and mild detergent and a microfiber cloth, thoroughly rinse, and dry with a soft cloth.

STORAGE: Ensure the accessories are completely cool before moving and storing them. Manufacturer is not liable for damage resulting from general use and/or environmental conditions. When not in use, store in a dry location that is protected from weather elements.

SAFETY STATEMENTS & WARNINGS

- Only use this charcoal basket with a compatible smoking/grilling unit.
- Cooking accessories become hot while in use. To prevent burns, use appropriate protective equipment and tools while in use.
- Do not allow children to use this product. Supervise children and pets at all times.
- DO NOT USE CHEMICAL-BASED CLEANERS as this may damage the product and/or ignite a flame during the next use.
- Always ensure components are completely cool before moving and/or storing.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1. Please have the item number and your order information ready to expedite response time.

WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.