

ASSEMBLY INSTRUCTION

ITEM# 6960-85002-45 Burnham Console
6960-85002-89 Burnham Console

**** Please make sure you have all parts indicated below prior to assembly.**
This console is heavy and can best be assembled with the help of two or more people.

NO.	HARDWARE LIST		Q'TY
A		$\frac{5}{16}$ " Flat Washer	8
B		$\frac{5}{16}$ " Lock Washer	8
C		$\frac{5}{16}$ " Bolt	8
D		73MM Allen Wrench	1
E		1/4" Bolt	4
F		1/4" Lock Washer	4
G		1/4" Flat Washer	4
H		69MM Allen Wrench	1






Diagram 1





Assembly Steps:

Note: There are removable wood chips adhered to corner blocks, pull them off before assembly and put them back after assembly. (See Diagram 1)

1. Place console top (I) upside down on a soft surface to prevent it from being scratched.
2. Attach legs (J) to top by using flat washers (A), lock washers (B) and bolts (C), tighten all with allen wrench (D) in clockwise direction. (See Diagram 2)
3. Attach bottom panel (K) between legs. Use flat washers (G), lock washers (F) and bolts (E), secure all by using allen wrench (H). (See Diagram 3)
4. Turn console upright.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.