HADLEY CAL KING / KING BED


ASSEMBLY INSTRUCTIONS





PARTS AND PACKAGING DETAIL

BOX #1

- A. HEADBOARD PANEL 1 PC
- **B. LEFT PANEL LEG 1 PC**
- C. RIGHT PANEL LEG 1 PC
- D. HEADBOARD STRETCHER 1 PC








BOX #2

E. FOOTBOARD 1 PC


H. SLAT ROLL 1 SET






HARDWARE PACKED IN BOX #1				HARDWARE PACKED IN BOX #2			
H1	ALLEN HEAD BOLT (M6x40)	9	2	Н6	ALLEN HEAD BOLT (M8x20)		8
Н2	ALLEN HEAD BOLT (M8x50)	(a) January	6	Н7	LOCK WASHER (M9x13)	0	8
Н3	LOCK WASHER (M9x13)	Ø	8	Н8	FLAT WASHER (M8x20)	0	8
H4	FLAT WASHER (M8x20)	0	8	Н9	ALLEN KEY		1
Н5	ALLEN KEY		1	H10	WOOD SCREW (M4x25)		4

TOOL REQUIRED: PHILLIPS HEAD SCREW DRIVER (NOT PROVIDED)








HADLEY CAL KING / KING BED


ASSEMBLY INSTRUCTIONS








STEP 3: USE HARDWARE PACKED IN BOX #2 FOR REMAINING STEPS




HADLEY CAL KING / KING BED

ASSEMBLY INSTRUCTIONS








HADLEY KING/ CAL KING BED


ASSEMBLY INSTRUCTIONS



STEP 6:



STEP 7:




INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your room. Locate levelers under each leg support.

Turn counter-clockwise to extend, clockwise to contract.

Adjust levelers until each leg support is applying equal upward pressure on the bed slat.



MAINTENANCE INSTRUCTION:

- Remove box spring and mattress before moving your bed
- Lift your bed when moving it. Dragging can damage leg support.
- Readjust levelers after moving your bed.