


# INSTRUCTION MANUAL



Kids Outdoor 24" Dining Table

V1.0

## ! NOTICE

Please keep this instruction for your future reference.

- Be careful when assembling, avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.

## TOOLS REQUIRED



TABLE  
300 LBS  
CAPACITY



1 PERSON  
ASSEMBLY




UP TO 20 MIN.  
ASSEMBLY

## HARDWARE

1

**SCREW**  
M6 x 70 mm




12 PCS

## PARTS

A


**TABLE TOP**



1 PC

B


**LEG I**



2 PCS

C

**LEG II**



2 PCS

D


**UMBRELLA  
COVER**



1 PC

## PRODUCT ASSEMBLY – OVERALL VIEW

Look at following overall view of this table and learn the exact position of each parts to be assembled.




## PRODUCT ASSEMBLY

1

Place **Part A Table Top** upside down on soft surface like carpet to avoid damage.

Attach **Part B Leg I** and **Part C Leg II** to the aprons of **Part A Table Top** as below with 6 pcs of **Hardware #1 Screw**.


Pay attention to match the holes in the aprons.



## PRODUCT ASSEMBLY

2

Do the same to attach the **Part B Leg I** and **Part C Leg II** to the aprons of **Part A Table Top** with 6 pcs of **Hardware #1 Screw**.




3

Check and tighten all the bolts again to ensure the table is steady enough.

Remove the **Umbrella Cover** to assemble the umbrella pole.

Enjoy this table now.



---

## CLEANING TIPS

**REGULAR CLEAN:** Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

**QUICK CLEAN:** You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.