



Purchase Date: \_\_\_ / \_\_\_ / \_\_\_ Order/Customer Reference #: \_\_\_\_\_

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: [customerservice@sunnydazedecor.com](mailto:customerservice@sunnydazedecor.com), or via our contact us page at <https://tiny.cc/SunnydazeContact>

# WOODEN BIRDHOUSE

## CLEANING

Ideally, a birdhouse should be cleaned after the nesting brood will not longer return to the nest. Ensure the birdhouse is not occupied before attempting to clean.

**IMPORTANT:** Damages caused by cleaning the birdhouse are not covered by warranty.

1. Remove all nesting material.
2. Mix a weak bleach solution of 1 part chlorine bleach with 9 parts water.
3. Use a soft-bristled bendable brush, such as a hook brush, to scrub the inside of the birdhouse.
4. Rinse thoroughly for several minutes to remove all traces of contaminants and bleach that could affect birds.
5. Allow the birdhouse to dry for several hours (or days) in direct sunlight. Sunlight will help break down any remaining chlorine and ensure water is not trapped in crevices for mold and mildew to grow.

**WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE USE OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, OR CLEANING PRODUCTS.**

**Any modification to the product or failure to follow recommended care will void the product warranty.**