

ROOFTITE® ROOF FLASHING

INSTALLATION INSTRUCTIONS

1. Clean roof surface to remove all dust, moss, oil or grease around the area the Rooftite will be secured to.
2. Choose the correct cutting line on the Rooftite to accommodate the correct pipe size.
3. Mould the Rooftite into the shape of the roof (if corrugated) before applying silicone sealant to the ribs on the underside of the Rooftite.
4. Push the Rooftite over the pipe and down to the correct position on the roof, then fasten to the roof with appropriate fastenings.

