



# ASSEMBLY INSTRUCTION

## BOOKCASE

**A** Left Top Frame      **B** Left Bottom Frame      **C** Right Top Frame      **D** Right Bottom Frame




1pc



1pc




1pc




1pc


**E** Shelf Frame      **F** Shelf Board - Short      **G** Top Panel      **H** Shelf Board - Long




3pcs



3pcs




1pc




2pcs


**I** Bottom Panel      **J** Bolt Ø1/4"X5/8"      **K** Bolt Ø1/4"X1-1/8"      **L** Bolt Ø1/4"X1-1/2"




1pc



10pcs



12pcs



22pcs


**M** Flat Washer Ø16mm      **N** Allen Key M4      **O** Anti-Tipping Kit




10pcs



1pc




1set




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Insert Left Bottom Frame (B) to the Left Top Frame (A), then using Bolt (J) & Flat Washer (M) to fasten by Allen Key (N).




- 2** Insert Right Bottom Frame (D) to the Right Top Frame (C), then using Bolt (J) & Flat Washer (M) to fasten by Allen Key (N).




- 3** Assemble Top Panel (G) to the Left Top Frame (A) & Right Top Frame (C), using Bolt (L) to fasten by Allen Key (N).




- 4** Insert 1pc Shelf Frame (E) to the Top Panel (G), then using Bolt (J) & Flat Washer (M) to fasten by Allen Key (N).




- 5** Assemble 1pc Shelf Board - Short (F) to Left Top Frame (A) & Shelf Frame (E), using Bolt (K) & Bolt (L) to fasten by Allen Key (N).




- 6** Assemble 1pc Shelf Board - Long (H) to Left Top Frame - Short (A), Shelf Frame (E) and Right Top Frame (C), using Bolt (K) & Bolt (L) to fasten by Allen Key (N).




- 7** Insert 1pc Shelf Frame (E) to the Shelf Board - Long (H), using Bolt (J) & Flat Washer (M) to fasten by Allen Key (N).




- 8** Assemble 1pc Shelf Board - Short (F) to Right Top Frame (C) and Shelf Frame (E), using Bolt (K) & Bolt (L) to fasten by Allen Key (N).




- 9** Assemble the rest 1pc Shelf Board (H) to Left Bottom Frame (B), Shelf Frame (E) and Right Bottom Frame (D), using Bolt (K) & Bolt (L) to fasten by Allen Key (N).




- 10** Insert the rest 1pc Shelf Frame (E) to the Shelf Board - Long (H), using Bolt (J) & Flat Washer (M) to fasten by Allen Key (N).




- 11** Assemble the rest 1pc Shelf Board - Short (F) to Left Bottom Frame (B) & Shelf Frame (E), using Bolt (K) & Bolt (L) to fasten by Allen Key (N).



- 12** Assemble Bottom Panel (I) to Left Bottom Frame (B), Shelf Frame - Short (E) & Right Bottom Frame (D), using Bolt (K) & Bolt (L) to fasten by Allen Key (N).



- 13** Remark: there is a tip restraint kit provided on the back of this product. Please read the instruction thoroughly and install immediately when placed in home. To prevent tip over, the product must be attached to wall.



Adjust any parts out of alignment and tighten all bolts and screws from steps 1 through 12.

### **Cleaning & Care**

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.