SMALL ENGINE OIL CHANGE KIT

INSTRUCTIONS:

1. Start your mower or small engine and allow it to warm up. After approx. 5 minutes turn the engine off.

ACAUTION: Oil and motor may be hot.

- 2. Put down newspaper or shop towels to catch any oil that may spill or drip.
- 3. Position the mower or small engine on the newspaper and stabilize so it won't tip or roll.
- 4. Connect the flexible hose to the syringe by inserting the end into the nipple at the front of the syringe.
- 5. Remove the dipstick/plug and insert the flexible syringe hose. Be sure to insert as far as it will go.
- 6. Slowly pull the center handle of the syringe to draw the oil in. Continue until full.
- 7. Remove the flexible hose from the dipstick or plug hole. Insert the end into the waste oil storage container and push the syringe's plunger back in.
- 8. Repeat steps 4-6 until all the oil has been removed. It may take a few times depending on capacity.
- 9. Use the supplied funnel to fill engine with new engine oil. Refer to the owner's manual for the type and amount of oil required.
- 10. Wait a few minutes and check the oil level with the dipstick. Engines without a dipstick get filled to the base of the plug port. Refer to the owner's manual for that procedure.
- 11. Replace dipstick or plug and tighten firmly.
- 12. Clean the area and dispose of used oil and newspaper per your city's recommended oil disposal.

