


Firmware Version Number

It is only checked by Data Transfer Software. Go to "Update Settings" tab, and press "Update Check" button under condition that the computer is connected to Internet.



Firmware Version Number

Check the serial number on the back of meter.

L-758D/DR

Version	Contents
12	First edition of firmware
20	* ControlTL implemented * Bug fixed (The display of incident/spot in Mid.Tone recall mode was wrong)
22	• Modification of flash measurement "Under" is displayed if flash component is under the measurement range even though ambient light is within the range (Up to version 20, only ambient light is displayed).

L-758CINE

Version	Contents
10	First edition of firmware
11	* Improvements for production procedure (no difference in functions)
21	* ControlTL implemented * But fixed (Exposure compensation is not referred in Illuminance or Luminance) * Bug fixed (The display of incident/spot in Mid.Tone recall mode was wrong)
22	• Modification of flash measurement "Under" is displayed if flash component is under the measurement range even though ambient light is within the range (Up to version 21, only ambient light is displayed).