


3-Drawer Changer (5925) - Assembly and Operation Manual

Congratulations on purchasing an MDB Family product. This product will provide many years of service if you adhere to the following guidelines for assembly, maintenance, and operation. This product is for residential use only. Any institutional use is strictly prohibited.

Please be sure to follow the instructions for proper assembly. Use a Phillips head screwdriver for assembling the product in addition to the Allen wrench included in the hardware box. Do not use power screwdrivers. All of our products are made from natural woods. Please understand that natural woods have color variations which are the result of nature and not defects in workmanship.


DO NOT SUBSTITUTE PARTS. ALL MODELS HAVE THE SAME QUANTITY OF PARTS AND HARDWARE. YOUR MODEL MAY LOOK DIFFERENT FROM THE ONE ILLUSTRATED DUE TO STYLISTIC VARIATIONS.




WARNING!

READ ALL INSTRUCTIONS BEFORE USE OF THE CHANGING TABLE, ADD-ON CHANGING UNIT, OR CHANGING PAD.


PARTS




A. Top Rear Panel



B. Top Front Panel




C. Top Changer Panel




D. Left End Panel

E. Right End Panel




F. Left/Right Drawer Panels L: 3, R: 3



H. Rear Drawer Panel x3




I. Drawer Board x3



G. Front Drawer Panel x3




J. Front Support Rails x3




J1. Back Bottom Support Rail x1


M. Back Panel Side Support Rail x 2



K. Back Board



L. Changer Board



N. Changer Pad


WARNING: USING ANY POWER TOOLS TO ASSEMBLE THIS FURNITURE MAY POTENTIALLY STRIP THE WOOD. DO NOT USE.

Hardware

Tools required: Phillips screwdriver, Flat-head screwdriver.



H1. Nylon Dowels x8




H2. Cam Bolts x 10



H3. Cam Locks x 10




H4. Knobs x6



H5. Knob Screw x6



H6. Small Wood Screw x36



H13. 1-3/4" Bolts x 16



H7. Large Wood Screw x12




H12-1. Safety Strap Screws with washers x 2



H12. Safety Strap x1




H8. Right Panel Glide x3



H10. Left Panel Glide x3







H9. Right Drawer Glide x3



H11. Left Drawer Glide x3

1



Install left panel glides (H10) on the left end panel (D) and right panel glides (H8) on the right end panel (E) with wood screws (H6).



Do not overtighten.

2

Insert nylon dowels (H1) into support rails (J and J1).




Align nylon dowels (H1) on support rails (J&J1) to the appropriate pre-drilled holes on left end panel (D).


Align top rear panel (A) and top front panel (B) to the appropriate pre-drilled holes on left end panel (D).

Use 1-3/4" bolts (H13) to fasten panels (A&B) and rails (J&J1) to left end panel (D).


Do not overtighten the bolts.

3

Place back panel side supports (M) on left and right side of back board (K) and slide in back board as shown in the above illustration.


4

Slide in changer board (L) to changer assembly.


**5**

Align A, B, J and J1 to the right end panel (E) and fasten with 1-3/4" bolt (H13) as illustrated.

6



Insert cam bolts (H2) into the top changer panel (C).




Attach top changer panel (C) to the changer assembly using 4 cam bolts (H2) and cam locks (H3).


7

DRAWER ASSEMBLY INSTRUCTIONS


7a




7b




7c




7d



7e




7f





8

* Slide the drawers into the changer and check that they glide smoothly.



9



10

FURNITURE ANTI-TIPPING KIT INSTALLATION

Serious or fatal crushing can occur when furniture tips over on children. To help prevent tip-over, follow the steps below to install this anti-tipping strap.




WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Install tipover restraint provided.
- Place heaviest item in the lowest drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- (OR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.


This is permanent label. Do not attempt to remove!




Tools Needed (not included)



Stubby
Screwdriver




Pencil



Phillips
screwdriver


10a

Locate a 2" x 4" stud behind the wall, and make a mark.




10b

Install the strap on the wall with long screw and washer.




10c

Install the other end of strap on the back of dresser with short screw and washer into the wood framing of the dresser.



Finish



The recommended maximum weight of the occupant is 30 lbs on changing table.

KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE.

READ ALL INSTRUCTIONS BEFORE USING THE PRODUCT. KEEP THE INSTRUCTIONS FOR FUTURE USE.

IMPORTANT:

As with all infant and baby furniture, it is important to check fasteners, screws, and bolts periodically for tightness. Parents should ensure a safe environment for their children by checking the furniture regularly before placing a child in the product.



WARNING! FALL HAZARD

TO PREVENT DEATH OR SERIOUS INJURY, ALWAYS KEEP CHILD WITHIN ARM'S REACH.

READ ALL INSTRUCTIONS BEFORE ASSEMBLING THIS PRODUCT. KEEP THE MANUAL FOR FUTURE USE.




WARNING:

- Always secure this pad to the changing surface (removable or stationary changing tray) by placing the pad within the boundaries of the tray. See instructions.
- The pad is to be used on a surface that is level, stable and structurally sound with a minimum surface dimension of 34" by 17".
- Read all instructions before use of the changing table.
- Do not use changing table if it is damaged or broken.
- This product is not intended to be used as a changing table without adult supervision. Use of the product without this may result in death or serious injury to your child from falling. Follow all instructions on attaching and using the changing table.
- Only use the pad provided by MDB FAMILY.
- The maximum weight of the child for which the changing table is intended is 30 lbs.
- Stop using this changing table when the child is able to sit up or roll over.
- As with all infant and baby furniture, it is important to check fasteners, screws, and bolts periodically for tightness. Parents should ensure a safe environment for their child by checking the furniture regularly before placing the child in the product.
- When using this product, always secure the child with the safety strip.



WARNING! FALL HAZARD

To prevent death or serious injury, always keep child within arm's reach. Never leave child unattended and always use restraining system.



ONE YEAR LIMITED WARRANTY:

We will replace any missing parts at the time of purchase or any defective item within a one year period from the date of original purchase. Please keep your receipt so that we may process your warranty request. This warranty only covers new units with original packaging and ownership, and is not transferable. It does not cover any used, second-hand or demo models.

This warranty does not cover any damaged or defective parts that result from installation and assembly, normal wear and tear, abuse, negligence, improper use or alteration to the finish, design, and hardware. The specific legal rights of this warranty may vary from state to state. Some states do not allow any exclusion or limitation of incidental damages. Some states do not allow limitation on how long an implied warranty lasts.

Storage:

- Pine woods exchange moisture with the air adjusting to major changes in room temperature and humidity. Therefore, it is best to place your furniture away from heating or air-conditioning vents.
- Sunlight is not friendly to solid wood furniture and prolonged direct exposure to harsh sunlight can discolor the finish. Be careful not to place your furniture in direct sunlight for extended periods of time. As with all your fine furniture, blot up spills immediately.

Care and Cleaning:

- Do not scratch or chip the finish. Do not use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly. If you ever refinish this furniture, be sure to use only a non-toxic finish specified for children's products. If you choose to refinish this furniture, the warranty will be voided.

Registering your product is even easier than before. You can register your product on our website at : www.themdbfamily.com

IF YOU WOULD LIKE TO ORDER REPLACEMENT OR MISSING PARTS PLEASE VISIT US AT:

WWW.THEMDBFAMILY.COM

OR YOU CAN CONTACT US BY MAIL:

MDB FAMILY

855 WASHINGTON BLVD.

MONTEBELLO, CA 90640

Restraint System

WARNING:

During the diaper changing process, be sure always to keep one hand on the baby to prevent the baby from falling off the changing pad. Falling from the changing pad could cause severe injury or even death to the baby.




Step 1.

Place a baby on the pad with his/her bottom on the top of the diaper. Safely secure the baby on the pad with the safety straps and buckle on the pad. This helps prevent the baby from falling off the pad, which can result in severe injury or even death of the baby.




Step 2.

Remove the dirty diaper from the baby.



Step 3.

Push the baby's legs forward and create a cavity under the baby's bottom. Clean the baby.



Step 4.

Reattach the new diaper to a clean and happy baby!