


W1000-72Z

Smart Side Table

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent damage to the parts.



We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

Assembly Instructions

To lift the table top, gently press on the top to unlock it and pull it upwards. The table can then be rotated 360 degrees. To lower the table top, swivel the top back to its original orientation, then press down on it until it locks in place. To reveal the hidden cup holders, pull open the door on the back panel. Adjust the levelers on the base of the unit until the furniture is leveled. (See Figure 1).




Figure 1

CARE INSTRUCTIONS

- To avoid scratches, do not place sharp or jagged objects directly on the table top.
- Do not place hot items directly on the table top.
- Use placemats or trivets under hot items and coasters under beverages to prevent marks and stains.
- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc.
For Parts or Customer Service call
toll-free:
1-888-415-3979
Monday-Friday
8:00 a.m. -5:00 p.m.
(Central Time)
Email:
customersolutions@flexsteel.com