


# COFFEE MUG HOLDER WITH HOOKS











## CFT-680

Review all assembly and care information carefully before using this product. Save this manual for future reference.  
**Assemble components on a soft, clean surface to avoid damaging the finish.**



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.  
 Save the packing slip.



No.	PARTS	QTY.
A	 Base Basket	1
B	 Bottom Rod	1
C	 Large Mug Holder	1
D	 Middle Rod	1
E	 Medium Mug Holder	1
F	 Upper Rod	1
G	 Small Mug Holder	1
H	 Handle	1
I	 M5x5mm Bolt	1
J	 Hex Key	1


### ! WARNING !

**CHOKING HAZARD** — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

# ASSEMBLY

## STEP 1


A: 1  
B: 1  
I: 1



Secure Bottom Rod (B) to the center of Base Basket (A) using M5x5mm Bolt (I), as shown.

## STEP 2


C: 1



With the hooks facing upward, place Large Mug Holder (C) onto the bottom rod.

## STEP 3


D: 1



Secure Middle Rod (D) by twisting it onto the bottom rod.

## STEP 4


E: 1



Place Medium Mug Holder (E) onto the middle rod.

## STEP 5


F: 1



Secure Upper Rod (F) by twisting it onto the middle rod.

## STEP 6


G: 1



Place Small Mug Holder (G) onto the upper rod.

## STEP 7

H: 1



Secure Handle (H) by twisting it onto the upper rod.

# Care & Maintenance

**SAFE USE:** For indoor use only. For residential use only. Only use on a flat, level surface. Remove mugs and empty the base basket before moving the unit.

**SCRATCHES:** The finish on this product is tough & durable but, even under normal use, some scratching is inevitable. Scratches can be repaired with rust-resistant paint (not included).

**WARNING:** THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

## Cleaning



HAND-WIPE ONLY



DO NOT USE BLEACH



NOT DISHWASHER SAFE

Do not submerge in water; use a soft, damp cloth to clean this unit. Use a soft, dry cloth or towel to remove excess moisture.

### SAFETY STATEMENTS & WARNINGS

- For indoor use only.
- For residential use only. Not for commercial or industrial use.
- Ensure all fittings are tight before use. Periodically check fittings to ensure they remain tight.
- Only use this unit on a flat, level surface.
- Do not exceed the weight capacity of the unit.
- Do not allow children to use this product.
- Never use chemical cleaning products or polishes as doing so may damage the finish.

**Any modification to the product or failure to follow recommended care will void the product warranty.**

*If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team directly through one of the methods mentioned at the top of page 1.*

*Please have the item number and order information ready to expedite response time.*

### WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.