


SHIMANO

STELLA SW

STLSW14000XGD



(51SF84DV45X)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

#	Part No.	RD No.	Description	#	Part No.	RD No.	Description	#	Part No.	RD No.	Description
1	14A3H		Drag Knob Assembly	54	146VN		Rotor Guard B	107	1015D	19586	Bushing
3	1077S	9501	Click Spring	55	146VU		Line Roller Plate	108	101NF	16996	O Ring
4	1036I	8076	Drag Click	56	1016K	19562	Line Roller Seal	109	147FU		Worm Shaft Retainer
5	14A69		Spool Assembly	57	104W1	7915	Ball Bearing	110	103EB	16478	Screw
6	146XH		Spool Ring Collar	58	1015A	19657	Bushing	111	147F6		Rear Protector
7	1015W	19673	O Ring	59	1015S	19638	O Ring	112	10L9D	8059	Screw
8	146XG		Spool Ring	60	1014P	19571	Bearing Spacer	113	14A3N		Main Shaft Assembly
9	10B88	12319	Retainer	61	146VT		Line Roller	114	106V5	12459	Oscillating Pawl
10	146VG		Key Washer	62	1014N	19559	Collar	115	14813		Washer
11	146VH		Drag Washer A	63	14A3K		Bail Assembly	116	10164	19583	Oscillating Slider Bushing
12	10BGC	10463	Ball Bearing	64	10Q3F	15798	Line Roller Support	117	146WE		Oscillating Pawl Cover
13	10EAG	19714	Spool Ring Pin	65	10153	19558	Bail Spring Guide B	118	10MT4	3561	Screw
14	10W8D	8291	O Ring	66	1015E	19568	Bail Spring	119	108W9	9968	O Ring
15	1016A	19641	Drag Washer C	67	10DUU	19570	Spring Guide A Support Collar	120	10AYL	15834	Rear Protector Collar
16	10C19	15771	Drag Washer B	68	1016J	19569	Bail Spring Guide A	121	10LSC	11633	Screw
17	10B58	15772	Drag Disk A	69	10R2F	19715	Bail Spring Guide A Bush	122	146XL		Idle Gear (Large)
18	10LWM	8292	Bearing Retainer	70	146WP		Bail Trip Lever	123	146WC		Idle Gear
19	146V3		Spool Bearing Bushing	72	10CYT	8227	Screw	124	146W0		Bearing Water Proof
20	1017T	19640	Drag Disk B	73	146VL		Bail Hold Support Guard	125	10BGG	15815	Bearing Washer
21	10RC9	19648	Bearing Water Proof	74	146VM		Rotor Guard A	126	104PW	14101	Ball Bearing
22	10W1L	19721	Washer	75	146VJ		Rotor	127	146VZ		Body Seal
23	109ZQ	15777	Drag Click Ratchet	76	147FE		O Ring	128	1486C		Drive Gear Assembly
24	100LX	21656	Drag Cover	77	146W2		Rotor Ring	129	14814		Washer
25	1014B	19645	Heat Sink	78	1015M	19534	Screw	130	14A3P		Side Cover Assembly
26	147FC		Screw	79	10LAD	16974	O Ring	131	10A6N	15721	Screw
27	1017R	19643	Spring Holder	80	10148	19612	Roller Clutch Water Proof Cover	132	10PVM	15819	Screw
28	10E90	19522	Drag Click Assembly	81	147FS		Roller Clutch Water Proof	133	10PVN	15820	Screw
29	1480N		Screw	82	1014F	19607	Roller Clutch Inner	134	14A6B		Handle Assembly
30	101DJ	19753	Spool Washer	83	10DUZ	19532	Roller Clutch Assembly	135	14A3R		Handle Shaft Cover Assembly
31	103MW	15780	Spool Support	84	1014X	19539	O Ring	136	10LAA	13673	O Ring
32	103LB	16426	Screw	85	10ML2	8144	Screw	137	146WL		Handle Shaft
33	10K30	15781	Nut Lock Plate	86	146W3		Bearing Retainer	138	14A3S		Handle Shank Assembly
34	147VW		Bearing Water Proof	87	10R1F	21491	Ball Bearing	139	10E85	19598	Handle Shaft Screw
35	14B4X		Washer	88	14A3U		Pinion Gear	140	147FX		Handle Knob Water Proof
36	10S4S	21481	Main Shaft Spacer	89	146XJ		Washer	141	104FH	19745	Washer
37	146VV		Rotor Nut	90	147FF		Spacer	142	105BN	10424	Ball Bearing
38	10163	19540	O Ring	91	147FT		Ball Bearing	143	146XQ		Handle Knob
39	146VW		Rotor Brim	92	104PN	10308	Bushing	144	10KX1	11706	Ball Bearing
40	1077Q	7919	Click Spring	93	146W5		Friction Ring	145	103E9	2110	Screw
41	10C8H	8008	Click Pin	94	1014J	19578	Idle Gear Spring	147	147F8		Handle Knob Seal
42	146VK		Bail Spring Cover	95	10R5T	22047	Idle Gear Shaft	148	14810		Washer
43	10CYU	9847	Screw	96	146WA		Body Flange Seal	151	146XN		Handle Knob ID Plate
44	10DN7	19712	Screw	97	10AYR	15710	O Ring	152	103NM	8174	Screw
45	10HDP	5917	Washer	98	108WP	12469	Handle Screw Cap	161	14CTH		Washer
46	146VP		Bail Arm	99	146WG		Body Assembly				
47	14859		Bail Arm Fin Assembly	100	14A6A		Oscillating Guide				
48	10K7M	15793	Collar	101	10147	19581	O Ring				
49	14A71		Washer	102	10JAB	16480	Worm Shaft				
50	147FH		Screw	103	146WB		Ball Bearing				
51	10PN1	12345	Set Screw	104	10PDA	11018	Washer				
52	10K46	12344	Screw	105	100XZ	19744	Washer	501	1485A		Bail Arm Fin B Assembly (accessory)
53	10MT2	18570	Screw	106	10TK0	18758	Washer	502	1485B		Handle Shaft (Right) Assembly (accessory)