
INSTRUCTION MANUAL



Poly Reclining Chaise Lounge Set With Table

TABLE OF CONTENTS

ASSEMBLY INSTRUCTIONS

Poly Reclining Chaise Lounge	3
Outdoor Poly Adirondack Side Table	9

INSTRUCTION MANUAL




Poly Reclining Chaise Lounge

! NOTICE


Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Be very careful when folding chair to avoid smashing your hands or fingers.






PARTS




PARTS



PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this chaise lounge and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY



Attach Part E Right Chair Arm to Part D Right Rear Leg with 4 sets of Hardware #2 Bolt, Hardware #5 Washer and Hardware #4 Nut.


Do the same to Part F Left Chair Arm and Part C Left Rear Leg.



2


Place Part A Lounge Backrest and Part B Lounge Base as below.

Attach the combined Part E Right Chair Arm and Part D Right Rear Leg to Part B Lounge Base with 3 pcs of Hardware #3 Bolt. Attach the combined Part E Right Chair Arm and Part D Right Rear Leg to Part A Lounge Backrest with 1 set of Hardware #1 Bolt, Hardware #5 Washer and Hardware #4 Nut.



3


Attach Part G Right Front Leg to Part B Lounge Base with 3 pcs of Hardware #3 Bolt.



4

Attach the combined Part C Left Rear Leg and Part F Left Chair Arm to Part B Lounge Base with 3 pcs of Hardware #3 Bolt.

Attach the combined Part C Left Rear Leg and Part F Left Chair Arm to Part A Lounge Backrest with 1 set of Hardware #1 Bolt, Hardware #5 Washer and Hardware #4 Nut. Attach Part H Left Front Leg to Part B Lounge Base with 3 pcs of Hardware #3 Bolt.




PRODUCT ASSEMBLY




Attach 4 pcs of Part I Rail between Part D Right Rear Leg and Part C Left Rear Leg as well as Part G Right Front Leg and Part H Left Front Leg with 8 pcs of Hardware #3 Bolt.

Tighten all the bolts and nuts again to finish the assembly.



Position the supporting pole into the brackets on the rear legs for a comfortable rest.

ATTENTION: You can choose from four adjustable positions (P1-P4 below).



INSTRUCTION MANUAL



Outdoor Poly Adirondack Side Table


! NOTICE

Do not overtighten screws or bolts. (Insert all screws before tightening screws.)


- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Avoid using strong power tools to prevent cracking the PE boards when assembling.


TABLE 1 PERSON UP TO 20 MIN. (PROVIDED) TABLE 100 LBS CAPACITY ASSEMBLY ASSEMBLY


HARDWARE



PARTS








PRODUCT ASSEMBLY




Attach Part B Table Leg to Part A Table Top with 2 pcs of Hardware #1 Bolt using an Allen Wrench.

Do not tighten the bolts too much at this stage.



2


Attach Part C Table Wooden Braces to Part B Chair Legs with 2 pcs of Hardware #1 Bolt.



3

Attach Part B Table Leg to Part A Table Top and Part C Wooden Brace with 2 pcs of Hardware #1 Bolt using an Allen Wrench.

Tighten all bolts and screws to finish the assembly.





CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.