


Pedestal Desk




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


Part List




B.
Side Panel
1 pc.




C.
Side Panel
1 pc.



D.
Middle Panel
1 pc.




E.
Middle Panel
1 pc.




P2.
Drawer
1 pc.


R2.
Drawer Back
2 pcs.




S2.
Drawer Back
2 pcs.




S3.
Drawer Side
2 pcs.



S4.
Drawer Side
2 pcs.



Q2.
Drawer Back
2 pcs.



For assembly see instructions in carton 20 05504 0181

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319