Assembly Guide








If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-950-4782.

Our customer service experts are trained to provide step-by-step instruction and can easily replace any missing or damaged parts.

Representatives are available Monday-Friday from 8:30 a.m. to 7:30 p.m. (ET)



Lot Code #

For best results, keep these tips in mind:

- 1 We know you want to finish this assembly as quickly as possible, but trust us: you'll have a better experience if you take it one step at a time.
- Q Give yourself some room to work near where you want the fully assembled product.
- If your floor isn't carpeted, assemble this product on the empty carton to avoid scratching.
- 4 Do you have a friend who owes you a favor? Some steps may go a little easier with a second set of hands.

DOs


- Use a #2 Phillips head screwdriver (or other handheld tools as indicated)
- Wear safety glasses at all times during assembly
- Carefully follow the instructions in this guide and complete all steps in order
- Give us a call if you're having trouble with a particularly tricky step

DON'Ts

- We know power tools are quick and easy, but you shouldn't use them when assembling this product (unless otherwise specified)
- Never move your furniture with items inside or resting on the surface
- Do not attempt to use this product before all steps have been completed



Watch assembly videos right on your phone or computer!



(Users of older smartphones may need to install a QR Reader.)

SCAN HERE



FOR VIDEOS

Or visit https://www.bushbusinessfurniture.com/ CustomerService/HowtoAssemble.aspx

IMPORTANT SAFETY INFORMATION




PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Warning	Do	Don't	Why it's important
Serious injury may occur.	Assemble following all instructions using all indicated parts and hardware provided.	 Do not move unit when loaded. Do not load with a television or other heavy equipment. Do not exceed the maximum load limits stated in the instructions. 	Improper assembly, use or loading can lead to product instability, tip-over or collapse.


Advertencia	Hacer	No	Por qué es importante
Se pueden producir lesiones graves.	Ensamble siguiendo todas las instrucciones utilizando todas las piezas y ferretería indicados provistos.	 No mueva la unidad cuando esté cargada. No cargue con un televisor u otro equipo pesado. No exceda los límites máximos de carga establecidos en las instrucciones. 	El ensamblaje, uso o carga inadecuados pueden provocar inestabilidad del producto, vuelco o colapso.

Avertissement	Faire	Ne le fais pas	Pourquoi c'est important
Des blessures graves peuvent survenir.	Assemblez en suivant toutes les instructions en utilisant toutes les pièces et le matériel indiqués fournis.	 Ne déplacez pas l'unité lorsqu'elle est chargée. Ne chargez pas avec un téléviseur ou un autre équipement lourd. Ne dépassez pas les limites de charge maximale indiquées dans les instructions. 	Un assemblage, une utilisation ou un chargement incorrects peuvent entraîner une instabilité du produit, un renversement ou un effondrement.





Fasteners are shown actual size.







Hardware not to scale.

















Go to Step 2. Proceda al paso 2. Allez à l'étape 2.




Go to Step 10. Proceda al paso 10. Allez à l'étape 10.




Go to Step 10. Proceda al paso 10. Allez à l'étape 10.














D

























Scan QR Code to Watch Video on:




How to Clean the Surface

Gently clean surfaces with a damp sponge eraser.





Congratulations! You are all done. If you have any questions or concerns, please call.















How to Tighten KD Cams



H71659










[2]


















A177102D












SCALE 4



Congratulations! You are all done. If you have any questions or concerns, please call.

WC12923

A[1] W206497

B[1] W206498

C[1] W186421

D[1] W177064

W206269 E[1]


5mm Hole Plug

[11] H73621

Cover Cap



[4]



WC24423

A[1] W206500

B[1] W206501

C[1] W186424

D[1] W177066

E[1] W206264

H92521

Cover Cap

[11]

H92523

5mm Hole Plug

[4]

H118700



[1]

WC36723

W206503 A[1]

B[1] W206504

C[1] W186423

D[1] W177068

E[1] W206270


H107306 [11]

Cover Cap

H107309



H118700




[1]

WC60323

A[1] W206506 B[1] W206507 C[1] W186425 D[1] W177071 E[1] W206271

H87676 (Cover Cap [11]





WC72423

A[1] W206509 B[1] W206501 C[1] W186424 D[1] W177066

E[1] W206264

H92523 5mm Hole Plug

[4]

H118700 [1]

H92521 (Cover Cap [11]