INSTRUCTION MANUAL



31.5" Outdoor Square Dining Table

! CARE & MAINTENANCE

- Be careful when assembly, avoid hurting the product.
- Clean the dust with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.


8 PCS

• Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.





2 PCS




8 PCS

8 PCS

PRODUCT ASSEMBLY - OVERALL VIEW

Look at the overall view of this table and learn the exact position of each part to be assembled.



PRODUCT ASSEMBLY


Slide Part B2 Leg II on Part B1 Leg I as shown below. Make sure the top of Part B1 & B2 are aligned and gently tap with a rubber mallet if necessary.



PRODUCT ASSEMBLY

2


Turn over the legs. Attach 2pcs of **Hardware #1 Self-tapping Screws** on the bottom of **Part B1 Leg I** by using an screwdriver. 100% tighten at this step.



PRODUCT ASSEMBLY

3

Put Part A Table Top upside down on a clean aground. Attach Combined Part (B1+B2) on the bottom of Part A Table Top with 8 sets of Hardware (#2 Bolt + #3 Lock Washer + #4 Flat Washer) by using an allen wrench. 100% tighten at this step.




PRODUCT ASSEMBLY



Adjust the feet levelers on the bottom of the legs for perfect balance.

Enjoy the table now.



adjustable feet leveler

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.