

Try this Creativity for Kids® kit!

#1793000 • Ages 7+
Quick Knit Loom



- Features 90 yards of chunky rainbow yarn, 2 faux-fur pom poms, knitting hook, round loom, felt patch, plastic needle and fully illustrated, step-by-step instructions.

- Everything included to create an adorable rainbow pom pom hat and heart-embellished cup cozy. Use it on your water bottle or favorite cup!



PLEASE RECYCLE!

The box can be recycled. Please follow the recommended guidelines for your area.

CREATIVITY counts

Creativity Can develop the skills needed to achieve lifelong success.

Creativity develops children's problem solving and critical thinking skills – it's the catalyst for invention, innovation and ideas that influence the future.

www.creativitycan.com



www.CreativityforKids.com

Quick Stitch Banner #6255000

© Faber-Castell USA, Inc. Cleveland, Ohio 44125

www.fabercastell.com

Designed in USA • Made in China

Conforms to ASTM D-4236 • Non-toxic • Safe for Children

Need Help?

Call Toll-Free: 800-311-8684

e-mail: consumer@fabercastell.com

Chat or view **FAQS & INFO** online:

supportcfk.fabercastell.com



#6255000

Ages 7+

QUICK STITCH BANNER

A little stitching, a little crafting, we give you everything you need to “quick stitch” this cute, quotable craft. It’s the perfect “I made it myself” accessory for your room.

GETTING STARTED


Work with clean hands on a clean work surface. Read the instructions or check out our YouTube video before you begin. Younger crafters may need a little help along the way.

Helpful Hint –To make stitching easier, work with a piece of yarn that’s about as long as your arm. When you reach the end of the yarn, knot it on the non-printed side of your canvas. Thread your needle with a new piece of yarn and keep stitching. **For even faster crafting, you can skip the stitching and just decorate your banner.**

THREAD THE NEEDLE

Starting with the blue yarn and needle threader, thread your needle as shown. Knot one end to hold it in place.

WARNING:
FUNCTIONAL SHARP POINT





STITCH THE LETTERS

To trace the letters of your banner, we recommend a back stitch (see diagram).

TIPS

- Always start and finish on the underside of your banner so the knots don't show.
- Leave enough yarn to knot before beginning with another strand.
- Thread your needle with a new piece of yarn as needed.
- **When done stitching, add small dots of glue to knots and allow to dry.**

For help & tutorials, head to [Youtube.com/FaberCastellUSA](https://www.youtube.com/FaberCastellUSA)




Use the holes in the canvas to measure the length of your stitches. Each stitch should be about **3-4 holes long**. Use the hole nearest to where you want your stitch to be. Continue stitching the letters using the rainbow yarn.

Use the remaining yarn for hanging and tying on your pompom raindrops.

SIMPLIFY IT - Use your needle to sew in and out of the holes instead of Back Stitching.

For extra security, place a little glue on the inside bottom of the pompom straw.

Add another dot of glue over each knot, including the knots on the cloud. This extra step will keep them from untying. When completely dry, trim any excess yarn below the knots.



GEMS, SUNSHINE AND BIRD

Use the self-adhesive rhinestones to decorate the rainbow. Start in the center of the rainbow and space them about 1 thumbprint apart.

Peel and press the glitter sun sticker and felt bird in place. Add on the bird wing, too.

*To remove paper backing, twist the fabric creating a small tear in the paper.



CRAFTING TIME

CLOUD

A. Separate the adhesive squares. Remove the top release paper and place the adhesive side against the the non-printed side of the cloud. Peel off the other side of the release paper.

B. Position the cloud so the holes are just below the bottom edge of the banner. Press firmly into place.



* Add a small amount of glue on back of the cloud as needed.


RAINBOW DROPS

Cut 11 (10 in/25.4cm) pieces of rainbow yarn following the measuring guide below.

Thread each piece onto the cloud using the needle threader.



Tie a knot on the back side of the cloud to secure the yarn.



Use the needle threader to add one pom pom on each string.



Position them at different levels by sliding them up and down the string. Tie the bottom of each into a double knot.

DISPLAY



BASIC


Slide the dowel rod through the top pocket of the banner. For a simple hanger, measure 3 pieces of 24 in/60.9cm yarn. Tie them as shown onto each end of the dowel rod leaving 1.5"/3.8cm tassel.

Now you can display this in your room or give it to a favorite friend or family member!



TWISTED

A. For a more decorative hanger, you can mix the blue and rainbow together. Measure 3 pieces of 24 in/60.9cm yarn. Tie them around one end of the dowel rod as shown, leaving a 1.5 in/3.8cm tassel.



B. Begin twisting the yarn. When it's completely twisted, tie the yarn to the other end of the dowel rod leaving a 1.5 in/3.8cm tassel. Separate the individual strands of yarn for a fuller tassel.

PRO TIP - Use a dot of the craft glue to secure the knots on the hanging yarn.

17 inches / 43.2cm

10 in/
25.4cm

12 in/
30.5cm