

homestyles®

20 05523 0691


Pantry

IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.


Do not use power tools above 8 volts to assemble.




Part List



A.
Door
2 pcs.




B.
Door
2 pcs.




C.
Side Panel
1 pc.



D.
Side Panel
1 pc.



E.
Side Panel
1 pc.



F.
Side Panel
1 pc.

For assembly see instructions in carton 20 05523 0692.

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319