# INSTRUCTION MANUAL



Patio Folding Highback Dining Chair


# ! NOTICE


## Do not overtighten screws. (Insert all screws before tightening screws.)


- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- When using an electric drill, please adjust its speed slowly to avoid screw slippage.




#### **PARTS**








# **PARTS**



## PRODUCT ASSEMBLY - OVERALL VIEW


Look at the overall view of this chair and learn the exact position of each part to be assembled.




#### **PRODUCT ASSEMBLY**

1

Attach Part A Chair Backrest to Part B Chair Seat with 1 pc of Hardware #3 Right Connector, 1 pc of Hardware #4 Left Connector, 2 pcs of Hardware #5 Barrel Nut and 4 pcs of Hardware #7 Washer.




Attach Part E Chair Rear Leg to Part A Chair Backrest with the other end of Hardware #3 Right Connector and Hardware #4 Left Connector, 2 pcs of Hardware #7 Washer and 2 pcs of Hardware #5 Barrel Nut.



#### **PRODUCT ASSEMBLY**


3

Attach Part C Chair Right Arm and Part D Chair Left Arm to Part A Chair Backrest with 2 pcs of Hardware #2 Screw and 2 pcs of Hardware #7 Washer.




4

Attach Part C Chair Right Arm to Part E Chair Rear Leg and Part B Chair Seat with 1 pc of Hardware #1 Bolt, 2 pcs of Hardware #8 Washer, 1 pc of Hardware #7 Washer and 1 pc of Hardware #6 Nut.



5

Adjust the backrest to the position you like and fasten the nut on the arm.



## **CLEANING TIPS**

**REGULAR CLEAN:** Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.