



Paradise In Your Backyard®

## Torch Stand Warnings & Instructions

### **WARNING:**

FOR OUTDOOR USE ONLY! KEEP OUT OF REACH OF CHILDREN AND PETS – NEVER LEAVE A BURNING TORCH UNATTENDED. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE.

- ONLY USE WITH TIKI® BRAND METAL AND BAMBOO PATIO TORCHES.
- DO NOT use with umbrellas or any other product.
- DO NOT tip torch as fuel can spill and cause fire or serious injury.

**CALIFORNIA PROP. 65 WARNING:** This product may contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm.

### **INSTRUCTIONS FOR USE:**

- Unscrew base key by turning in a counter-clockwise direction.
- Insert torch pole into stand a minimum of 4" and tighten by turning base key clockwise.
- Do not over tighten.

©2015 Lamplight Farms Inc. , W140 N4900 Lilly Rd., Menomonee Falls, WI 53051  
TIKI®, TIKI TORCH® & Paradise In Your Backyard® are trademarks of Lamplight Farms Inc. TIKI®, TIKI TORCH® y Paradise In Your Backyard® son marcas de Lamplight Farms Inc.  
[www.tikibrand.com](http://www.tikibrand.com)  
Made in China/Hecho en China  
Customer Service/Servicio al cliente: 1-888-473-1088

### **ADVERTENCIA:**

PARA USO EN EXTERIORES SOLAMENTE. MANTENGA ALEJADO DEL ALCANCE DE LOS NIÑOS Y LAS MASCOTAS. NUNCA DEJE UNA ANTORCHA ENCENDIDA SIN SUPERVISIÓN. SI NO RESPETA LAS ADVERTENCIAS E INSTRUCCIONES PUEDE PRODUCIR LESIONES PERSONALES O DAÑOS MATERIALES GRAVES.

- utilice únicamente con las antorchas para patio de metal y bambú de la marca tiki®
- No utilice con sombrillas ni con ningún otro producto.
- No incline la antorcha, ya que el combustible puede derramarse y causar incendios o lesiones serias.

### **INSTRUCCIONES DE USO:**

- Desatornille girando la chaveta de la base en el sentido antihorario.
- Inserte el poste de la antorcha en el soporte un mínimo de 4" (10,2 cm) y apriete girando la chaveta de la base en el sentido horario.
- No apriete demasiado.