

Model/Modelo/Modèle
37984

RP52593
Stream Straightener,
Gasket & Wrench
Enderezador delChorro,
Empaque y Llave
Concentrateur de Jet,
Joint et Clé



RP73840
Spout Ring
& O-Rings
Aro Para el Surtidor
y Anillos "O"
Anneau du Bec et
Joints Toriques



RP73178
Set Screw & Button
Tornillo de Ajuste
Vis de calage



RP23094 ▲
Handle Base & Gasket
Base de la Manija y Empaque
Manette base et joint

RP73839 ▲
Handle Assembly
Ensamble de la Manija
Manette



RP52139
Set Screw
Tornillo
Vis



RP41896
Glide Ring
Aro para Deslizar
L'anneau de Glissement



RP20368
Gasket
Empaque
Joint




RP40510
End Valve Assembly
Ensamble de la válvula final
Soupape

RP40616
Test Cap
Tapa de prueba
Bouchon d'essai




RP40509
Spout Adapter Assembly
Ensamble del Adaptador
del Tubo de Salida
Adaptateur du bec




RP40504
Top Washer
Arandela superior
Rondelle supérieure




RP40503
Jack Screw
Gato de Tornillo
Vis d'ajustement



RP40506
Bottom Washer
Arandela Inferior
Rondelle inférieure




RP18362
O-Ring
Anillo "O"
Joint torique




RP18361
Tee
Codo T
Raccord en T




RP40505
Top Washer
Arandela superior
Rondelle supérieure



RP40503
Jack Screw
Gato de Tornillo
Vis d'ajustement



RP40507
Bottom Washer
Arandela Inferior
Rondelle inférieure




RP6060
Bonnet Nut
Bonete
Chapeau



RP24096
Stem Assembly
Ensamble de la unidad de la espiga
Obturateur



RP4993
Seat and Spring
Asiento y Resorte
Siège et ressort



▲Specify Finish/Especifique el Acabado /Précisez le Fini