


# INSTRUCTION MANUAL



Outdoor Poly Bar Chair Set  
with Connecting Tray & Cup Holder

**V1.0**

## ! CARE & MAINTENANCE

### Please keep this instruction for your future reference.

- Be careful when assembling, avoid damaging the painted surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all connections before use. Do not use any part of this item as a step ladder.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Please do not exceed the weight limitations of this item.

## NO TOOLS REQUIRED



CHAIR  
400 LBS  
CAPACITY



1 PERSON  
ASSEMBLY




UP TO 20 MIN.  
ASSEMBLY

## PARTS

**A**


**BACKREST**



2 PCS

**B**

**CHAIR SEAT**



2 PCS

**C**

**RIGHT ARM I**



1 PC

**C1**

**RIGHT ARM II**



1 PC

**D**

**LEFT ARM I**



1 PC

**D1**

**LEFT ARM II**



1 PC

## PARTS

**E**

**RAIL**



6 PCS

**F**

**SUPPORTING  
RAIL**



2 PCS

**G**


**LEFT LEG I**



1 PC

**G1**

**LEFT LEG II**



1 PC

**H**

**RIGHT LEG I**



1 PC

**H1**

**RIGHT LEG II**



1 PC

**I**

**FOOTREST**



2 PCS

**J**

**CONNECTING  
BRIDGE**



1 PC

**K**

**REAR  
CONNECTING RAIL**



1 PC

**L**


**FRONT  
CONNECTING RAIL**



1 PC

**M**


**CONNECTING  
TRAY**



1 PC

**N**


**UMBRELLA  
HOLDER**



1 PC

## PRODUCT ASSEMBLY – OVERALL VIEW

Look at following overall view of this chair set and learn the exact position of each part to be assembled.






## PRODUCT ASSEMBLY

**1**


Attach **Part H Right Leg I** to **Part A Backrest** by following the steps below:

1. Place **Part H Right Leg I** on flat surface. Make sure the cup holder is facing forward.
2. Press the upper bar of the backrest into the positioning slot of the leg (Figure 1).
3. Insert the lower bar into the holding position of the leg (Figure 2).



**2**

Do the same to attach **Part G Left Leg I** to **Part A Backrest**.




---

## PRODUCT ASSEMBLY

**3**

Insert **Part B Chair Seat** to the assembled frame until the groove sits in the slot in the legs (Figure 1). Keep the seat angled upwards as below.


Pay attention not to press down the seat at this stage.



**4**

Place **Part F Supporting Rail** between 2 pcs of the legs as below. Make sure the tenons with grooves are facing downward (Figure 1).

Press hard on **Part F Supporting Rail** to lock the tenons firmly into the mortise in the legs (Figure 2).




## PRODUCT ASSEMBLY

5

Press the seat down until it is locked on the supporting rail firmly.

Place **Part E Rail** between **Part G Left Leg I** and **Part H Right Leg I** as below. Make sure the arrows are inside and pointing downward (Figure 1).


Press hard on **Part E Rail** to lock the tenons firmly into the mortise in the legs (Figure 2).



6

Place **Part I Footrest** between **Part G Left Leg I** and **Part H Right Leg I** as below. Make sure the arrows are inside and pointing downward (Figure 1).

Press hard on **Part I Footrest** to lock the tenons firmly into the mortise in the legs (Figure 2).




## PRODUCT ASSEMBLY

7

Place 2 pcs of **Part E Rail** between **Part G Left Leg I** and **Part H Right Leg I** as below. Make sure the arrows are inside and pointing downward (Figure 1).

Press hard on **Part E Rail** to lock the tenons firmly into the mortise in the legs (Figure 2).




8

Attach **Part C Right Arm I** to **Part H Right Leg I** by following the steps below:

1. Match the groove in **Part C Right Arm I** with the tenon on top of **Part H Right Leg I** and slide the arm horizontally backwards (Figure 1).


2. Pull the arm upwards when it moves to the lock. Slide again till the lock is trapped in the groove (Figure 2).



## PRODUCT ASSEMBLY

9


Do the same to attach **Part D Left Arm I** to **Part G Left Leg I**.



10

Attach **Part H1 Right Leg II** to **Part A Backrest** by following the steps below:


1. Place **Part H1 Right Leg II** on a flat surface. Press the upper bar of the backrest into the positioning slot of the leg (Figure 1).
2. Insert the lower bar into the holding position of the leg (Figure 2)



## PRODUCT ASSEMBLY

11


Do the same to attach another **Part G1 Leg II** to **Part A Backrest**.



12

Insert **Part B Chair Seat** to the assembled frame until the groove sits in the slot in the legs (Figure 1). Keep the seat angled upwards as below.

Pay attention not to press down the seat at this stage.




## PRODUCT ASSEMBLY

**13**

Place **Part F Supporting Rail** between 2 pcs of the legs as below. Make sure the tenons with grooves are facing downward (Figure 1).


Press hard on **Part F Supporting Rail** to lock the tenons firmly into the mortise in the legs (Figure 2).



**14**

Place **Part E Rail** between **Part G1 Left Leg II** and **Part H1 Right Leg II** as below. Make sure the arrows are inside and pointing downward (Figure 1).

Press hard on **Part E Rail** to make the tenons locked firmly into the mortise in the legs (Figure 2).




## PRODUCT ASSEMBLY

15

Place **Part I Footrest** between **Part G1 Left Leg II** and **Part H1 Right Leg II** as below:  
Make sure arrows are inside and pointing downward (Figure 1).

Press hard on **Part I Footrest** to lock the tenons firmly into the mortise in the legs (Figure 2).


Press the seat down until it is locked on the supporting rail firmly.



16

Place 2 pcs of **Part E Rail** between **Part G1 Left Leg II** and **Part H1 Right Leg II** as below.  
Make sure the arrows are inside and pointing downward (Figure 1).

Press hard on **Part E Rail** to lock the tenons firmly into the mortise in the legs (Figure 2).






## PRODUCT ASSEMBLY

17


Attach **Part C1 Right Arm II** to **Part H1 Right Leg II** by following the steps below:

1. Match the groove in **Part C1 Right Arm II** with the tenon on top of **Part H1 Right Leg II** and slide the arm horizontally backwards (Figure 1).
2. Pull the arm upwards when it moves to the lock. Slide again till the lock is trapped in the groove (Figure 2).



18

Do the same to attach **Part D1 Left Arm II** to **Part G1 Left Leg II**.




---

## PRODUCT ASSEMBLY

19


Place the 2 pcs of assembled chairs in the position shown below.



20

Connect two chairs with **Part J Connecting Bridge**. Keep the groove downwards with its short edge facing the front.

Press hard on the connecting bridge until it trapped firmly into the legs of both chairs.




Keep the groove downward and short edge facing front.

## PRODUCT ASSEMBLY

21


Place **Part L Front Connecting Rail** between two chairs as below. Make sure the arrows are inside and pointing downward (See Figure 1).

Press hard on **Part L Front Connecting Rail** to make the tenons lock firmly into the mortise in the legs (Figure 2).



22


Do the same to attach **Part K Rear Connecting Rail** to two chairs as below.



## PRODUCT ASSEMBLY

**23**


Align **Part N Umbrella Holder** to **Part J Connecting Bridge**. Turn it clockwise to attach the umbrella holder to the connecting bridge.



**24**

Place **Part M Connecting Tray** onto the arms of both chairs. Align the arms with the grooves at the bottom of the connecting tray.

Press hard on the connecting tray until the arms are connected to the tray firmly.




---

## PRODUCT ASSEMBLY

**25**

Check and tighten all the connections again to ensure the chair set is steady enough.  
Enjoy the chair set now.



---

## CLEANING TIPS

**REGULAR CLEAN:** Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

**QUICK CLEAN:** You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.