



ASSEMBLY INSTRUCTION

PT - OF0010 80 Gallon Wicker Storage Box



















ASSEMBLY INSTRUCTIONS

ATTENTION: THIS PRODUCT IS NOT FOR COMMERCIAL USE INTENDED FOR RESIDENTIAL USE ONLY.

PT - OF0010


PARTS LIST

PART NO.	MATERIAL CODE	PART	QTY
1	74-0002-01	FRAME TOP	1
2	74-0002-02	FRONT &BACK FRAME	2
3	74-0002-03	LEFT FRAME	1
ЗА	74-0002-03A	RIGHT FRAME	1
4	74-0002-04	BOTTOM FRAME	1
5	74-0002-05	LINER BAG	1


PART NO.	MATERIAL CODE	PART		Q'TY
6	74-0002-06	GAS LIFT		1
7	74-0002-07	SCREW M4*30	S	6
8	74-0002-08	SCREW DRIVER		1
9	74-0002-09	BOLT M6*15	9	12
10	74-0002-10	WASHER d7*D20*2	0	12
11	74-0002-11	ALLEN KEY M4		1

Attention:

Make sure that each bolt needed for all steps matches the corresponding figure to ensure proper assembly.





Step 1: Put (4) on (2) as shown in figure 1, using Bolts (9) and Washers(10) with Allenkey (11) to position (4) and (2)




Step 2: Assemble (3) tp (2) by using Bolts (9)and Washers(10) with Allenkey (11) , please make sure that the 3A should be on the left hand side a shown in Figure 2

⚠ Keep children away during assembly. This item contains small parts that can be swallowed by children. Retain these assembly instructions for future reference.







Cleaning and Maintenance

- Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame parts.
- We recommend the use of furniture covers when not in use.
- Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your Wicker Storage Box.
- In order to prolong the life and beauty of your Wicker Storage Box, we recommend that it be stored in a dry and protected area during off season periods.
- ⚠ Please keep children out of reach of the cushion box without surveillance, the cover part may hurt their hands.