


SIMPLIHOME®

Cypress / Bloomsbury / Oceanview

7 Piece Outdoor Dining Set

Model # AXCPTDS7-CYP



brooklyn + max™

WyndenHall™
HOME DECOR

SIMPLIHOME

Great quality is a right.

Thank you for shopping with Simpli Home,
America's top brand for high-value furniture.



It's time to register your product warranty.

It's quick and easy. And you'll be happy you did.



- ✓ Activate your **1-year** warranty
- ✓ Automatic entry to win a **\$500** gift certificate
- ✓ Earn instant rewards and **save**

simpli-home.com/product-registration

SIMPLIHOME

Review your product and collect rewards!


Thank you for your purchase! We hope you enjoy it. We'd love your feedback. Please share a review and get instant rewards!




simpli-home.com/product-review



Share photos and get your cash back!



Send us images or share them on social and qualify for instant rewards. You may even receive store credit on your entire purchase!



simpli-home.com/share-images

SIMPLIHOME®

For Fastest Customer Service:



1. Open your phone's camera.
2. Point your phone's camera at the QR code to scan.
3. Click on the pop up.
4. You'll be taken to our customer service page.
5. Fill the form with your order information and issue.
6. Submit form.
7. A customer service associate will contact you.

Other ways to contact us...



Email Us

customerservice@simpli-home.com



Visit Us

Visit our site directly at
www.simpli-home.com



Call Us

1-866-518-0120
Monday to Friday
9am to 5pm EST

***If you've purchased from a retailer and you wish to return the product, please contact the retailer directly.**

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Safety Information

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required.

Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during Assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of Assembly.

Care & Maintenance

This furniture is designed for outdoor use.

Coffee Table / Dining Table

Wash frame parts with mild soap and water, rinse thoroughly and dry frame completely.

Do not use bleach, acid or other solvents on the frame parts.

Use placemats or coasters to prevent leaving marks from hot plates or cold glasses.

Inspect and tighten all bolts and fasteners on a regular basis to ensure proper performance.

Conversation Chair / Sofa / Dining Chair

Wash frame parts with mild soap and water, rinse thoroughly and dry frame completely.

Do not use bleach, acid or other solvents on the fabric or frame parts.

Cushions and pillows may be washed on the surface by using mild soap and water if necessary. Rinse well and hang to dry. Do not machine wash or dry.

Inspect and tighten all bolts and fasteners on a regular basis to ensure proper performance and safety.

To help protect your furniture, follow these steps:


- Wipe down the surface with a damp, soft cloth
- Wipe up spills promptly
- Clean with a dry cloth
- Do not use abrasive cleaners, chemical solvents, strong detergents, cleaners with bleach and furniture polish
- We recommend the use of furniture covers when not in use
- To prolong the life and beauty of your furniture, store it in a dry and protected area during off season periods

SIMPLIHOME®

Cypress / Bloomsbury / Oceanview

Outdoor Dining Chair Set of 2

Model # AXCPTDCH-CYP



brooklyn + max™


Wynden Hall™
HOME DECOR

Pre-Assembly Information

Model # AXCPTDCH-CYP


Part Description

A




CHAIR SEAT CUSHION
QTY 2

B




CHAIR SEAT
QTY 2

CL




LEFT BACK LEG
QTY 2

CR




RIGHT BACK LEG
QTY 2

DL



LEFT FRONT LEG
QTY 2


DR



RIGHT FRONT LEG
QTY 2

Hardware Description

1




ALLEN KEY BOLT
Ø6 X 20 mm
QTY 24

2




LOCK WASHER
Ø15 / Ø6 X 2 mm
QTY 24

3




WASHER
Ø16 / Ø6 X1 mm
QTY 24


4



ALLEN KEY
QTY 1



Step 1




1. Attach Legs (CL, CR, DL, DR) to Seat (A) using twelve Allen Key Bolts (1), twelve Lock Washer (2), twelve Washer (3) through guide holes.
2. Use Allen Key (4) to tighten Bolts. Do not over-tighten.

SIMPLIHOME®

Cypress / Bloomsbury / Oceanview

Outdoor Dining Table

Model # AXCPTDT-CYP



brooklyn + max™

WyndenHall™
HOME DECOR

Part Description

A






TABLE TOP
QTY 1

B



SUPPORT FRAME
QTY 1


C



LEG
QTY 2


Hardware Description

1



ALLEN KEY BOLT
Ø8 X 60 mm
QTY 8

2




ALLEN KEY BOLT
Ø8 X 40 mm
QTY 1

3




LOCK WASHER
Ø15 / Ø8 X 2 mm
QTY 9

4




WASHER
Ø16 / Ø8 X 1 mm
QTY 9


5



ALLEN KEY
QTY 1




Step 1



1. Attach Legs (C) to Support Frame (B) using Allen Key Bolts (1), Washers (3), Lock Washers (2) through guide holes.
2. Use Allen Key (4) to tighten Bolts. Do not over-tighten.

Step 2



1. Attach the frame assembled to Top (A) using Allen Key Bolts (1), (2), Washers (3), Lock Washers (2) through guide holes.
2. Use Allen Key (4) to tighten Bolts. Do not over-tighten.