


**homestyles®**

6800-401

## Sectional




### IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


### Part List




A.  
Back  
2 pcs.




B.  
Seat  
2 pcs.




O.  
Back  
1 pc.



P.  
Seat  
1 pc.



C.  
Side  
2 pcs.




D.  
Frame  
4 pcs.



E.  
Foot  
12 pcs.


### Hardware List



Hex Wrench  
1 pc.



Small  
Hex Wrench  
1 pc.



M6x35  
Head Cap Bolt  
64 pcs. (+1 extra)



Spring Washer  
64 pcs. (+1 extra)



Flat Washer  
64 pcs. (+1 extra)

**homestyles** Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
[servicedesk@homestylesfurniture.com](mailto:servicedesk@homestylesfurniture.com), 888-680-7460

## Assembly Instructions 2/7

### IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- The unit must be level to work properly. Use the included adjustable levelers to level.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

### Left Unit

#### STEP 1

Attach Seat (B) to Back (A) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.  
(See Figure 1)





Figure 1



#### STEP 2

Attach unit to Side (C) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.  
(See Figure 2)






Figure 2

### STEP 3

Attach Frame (D) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.

Tighten all bolts used in Steps 1, 2 and 3.

Flat Washer  
Spring Washer  
Head Cap Bolt



Head Cap Bolt  
Spring Washer  
Flat Washer





Figure 3


### STEP 4

Attach Feet (E) to unit with Head Cap Bolts, Spring Washers and Flat Washers. (See Figure 3)

### Right Unit


#### STEP 5

Attach Seat (B) to Back (A) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.



#### STEP 6



Attach unit to Side (C) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.



### STEP 7

Attach Frame (D) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.

Tighten all bolts used in Steps 5, 6 and 7.




### STEP 8

Attach Feet (E) to unit with Head Cap Bolts, Spring Washers and Flat Washers.

### Middle Unit


#### STEP 9

Attach Seat (P) to Back (O) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.



#### STEP 10


Attach Frame (D) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.



### STEP 11

Attach Frame (D) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.

Tighten all bolts used in Steps 9, 10 and 11.



### STEP 12

Attach Feet (E) to unit with Head Cap Bolts, Spring Washers and Flat Washers.

To complete assembly, follow instructions in 6800-402 carton.

# CARE INSTRUCTIONS

## NEVER

allow liquids to remain on furniture.  
Absorption causes parts to warp  
and split and finishes to delaminate.


## NEVER

use glass cleaners on  
finished furniture. Ammonia  
chemically attacks the finish.



Do not use power tools  
above 8 volts to assemble.

**PREVENT  
CRACKING**



Do not place  
in direct sunlight.

**PREVENT  
FADING**




Do not write  
directly on surface.

**PREVENT  
MARKING**



Do not place hot  
objects on surface.

**PREVENT  
FINISH DAMAGE**



Do not use rubber  
based placemats.

**PREVENT  
DISCOLORING**



Do not use commercial  
waxes and polishes.

**PREVENT  
YELLOWING**

## CLEAN

with a soft cloth moistened  
in lukewarm soap and water.  
Buff with a dry clean cloth.




**homestyles** will provide replacements free of charge for missing or damaged parts within 1 year of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **homestyles** is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

**homestyles** Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
[servicedesk@homestylesfurniture.com](mailto:servicedesk@homestylesfurniture.com), 888-680-7460



**homestyles®**

## 6800-402 Sectional




### IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


### Part List




L.  
Back  
1 pc.




M.  
Seat  
1 pc.




N.  
Back  
1 pc.




E.  
Foot  
4 pcs.



H.  
Seat Cushion  
1 pc.



I.  
Back Cushion  
1 pc.




K.  
Back Cushion  
1 pc.




J.  
Clip  
6 pcs.


### Hardware List



Hex Wrench  
1 pc.



Small  
Hex Wrench  
1 pc.



M6x35  
Head Cap Bolt  
18 pcs. (+1 extra)



Spring Washer  
18 pcs. (+1 extra)



Flat Washer  
18 pcs. (+1 extra)

Cartons 6800-401 and 6800-CUS3 are also needed for assembly.

**homestyles** Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
[servicedesk@homestylesfurniture.com](mailto:servicedesk@homestylesfurniture.com), 888-680-7460

## Assembly Instructions 2/7

### IMPORTANT



- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- The unit must be level to work properly. Use the included adjustable levelers to level.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

Follow instructions in 6800-401 carton first, then proceed with Step 13.

### Corner Unit

#### STEP 13

Attach Seat (M) to Back (N) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.



#### STEP 14



Attach Back (L) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.

## Assembly Instructions 3/7

### STEP 15

Insert Head Cap Bolts, Spring Washers and Flat Washers into unit, tightening bolts only halfway.

Tighten all bolts used in Steps 13, 14 and 15.



### STEP 16

Attach Feet (E) to unit with Head Cap Bolts, Spring Washers and Flat Washers.

For a 4 seat sectional, complete Steps 17 and 18.

For a 5 seat sectional, follow instructions in 6800-58 carton, then complete Steps 19 and 20.

For a 6 seat sectional, follow instructions in 2 6800-58 cartons, then complete Steps 21 and 22.

For a 7 seat sectional, follow instructions in 3 6800-58 cartons, then complete Steps 23 and 24.

## 4 Seat Sectional

### STEP 17

Attach left unit, middle unit, corner unit and right unit with Clips (J).  
(See Figure 4)




Figure 4






Figure 5

### STEP 18

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit.  
(See Figure 5)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit.  
(See Figure 6)




Figure 6

## 5 Seat Sectional

### STEP 19

Attach left unit, middle units, corner unit and right unit with Clips (J).  
(See Figure 7)




Figure 7






Figure 8

### STEP 20

6800-CUS carton is also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit.  
(See Figure 8)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit.  
(See Figure 9)




Figure 9

## 6 Seat Sectional

### STEP 21

Attach left unit, middle units, corner unit and right unit with Clips (J).  
(See Figure 10)




Figure 10






Figure 11

### STEP 22

Two 6800-CUS cartons are also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit.  
(See Figure 11)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit.  
(See Figure 12)




Figure 12



## 7 Seat Sectional

### STEP 23

Attach left unit, middle units, corner unit and right unit with Clips (J).  
(See Figure 13)




Figure 13






Figure 14

### STEP 24

Three 6800-CUS cartons are also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit.  
(See Figure 14)

Place Seat Cushion (H) and Back Cushions (I), (K) into position.

Level unit by adjusting the adjustable levelers on bottom of unit.  
(See Figure 15)




Figure 15

# CARE INSTRUCTIONS

## NEVER

allow liquids to remain on furniture.  
Absorption causes parts to warp  
and split and finishes to delaminate.


## NEVER

use glass cleaners on  
finished furniture. Ammonia  
chemically attacks the finish.



Do not use power tools  
above 8 volts to assemble.

**PREVENT  
CRACKING**



Do not place  
in direct sunlight.

**PREVENT  
FADING**




Do not write  
directly on surface.

**PREVENT  
MARKING**



Do not place hot  
objects on surface.

**PREVENT  
FINISH DAMAGE**



Do not use rubber  
based placemats.

**PREVENT  
DISCOLORING**



Do not use commercial  
waxes and polishes.

**PREVENT  
YELLOWING**

## CLEAN

with a soft cloth moistened  
in lukewarm soap and water.  
Buff with a dry clean cloth.



**homestyles** will provide replacements free of charge for missing or damaged parts within 1 year of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **homestyles** is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

**homestyles** Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
[servicedesk@homestylesfurniture.com](mailto:servicedesk@homestylesfurniture.com), 888-680-7460





**IMPORTANT**


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.


Do not use power tools above 8 volts to assemble.

**Part List**

O.  
Back  
1 pc.



P.  
Seat  
1 pc.




D.  
Frame  
2 pcs.



E.  
Foot  
4 pcs.




J.  
Clip  
2 pcs.

**Hardware List**

Hex Wrench  
1 pc.



Small  
Hex Wrench  
1 pc.



M6x35  
Head Cap Bolt  
20 pcs. (+1 extra)



Spring Washer  
20 pcs. (+1 extra)



Flat Washer  
20 pcs. (+1 extra)

## Assembly Instructions 2/5

### IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- The unit must be level to work properly. Use the included adjustable levelers to level.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

### Middle Unit

#### STEP 1

Attach Seat (P) to Back (O) with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway. (See Figure 1)






Figure 1



#### STEP 2


Attach Frame (D) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.



## STEP 3

Attach Frame (D) to unit with Head Cap Bolts, Spring Washers and Flat Washers, tightening bolts only halfway.

Tighten all bolts used in Steps 1, 2 and 3.



## STEP 4

Attach Feet (E) to unit with Head Cap Bolts,  
Spring Washers and Flat Washers.  
(See Figure 2)

## Assembly Instructions 4/5

For a sofa, follow instructions in 6800-57 carton, then complete Steps 5 and 6.

For a 5, 6 or 7 seat sectional, follow instructions in 6800-401 and 6800-402 cartons.

### Sofa

#### STEP 5

Attach left unit, middle unit and right unit with Clips (J).  
(See Figure 3)





Figure 3




Figure 4




Figure 5

## STEP 6

Three 6800-CUS cartons are also needed for this step.

Turn unit to its upright position.

Attach Seat Cushions (F) to unit by pushing toggles through weaving in back of unit.  
(See Figure 4)

Place Back Cushions (G) into position.

Level unit by adjusting the adjustable levelers on bottom of unit.  
(See Figure 5)

# CARE INSTRUCTIONS

## NEVER

allow liquids to remain on furniture.  
Absorption causes parts to warp  
and split and finishes to delaminate.


## NEVER

use glass cleaners on  
finished furniture. Ammonia  
chemically attacks the finish.



Do not use power tools  
above 8 volts to assemble.

**PREVENT  
CRACKING**



Do not place  
in direct sunlight.

**PREVENT  
FADING**




Do not write  
directly on surface.

**PREVENT  
MARKING**



Do not place hot  
objects on surface.

**PREVENT  
FINISH DAMAGE**



Do not use rubber  
based placemats.

**PREVENT  
DISCOLORING**



Do not use commercial  
waxes and polishes.

**PREVENT  
YELLOWING**

## CLEAN

with a soft cloth moistened  
in lukewarm soap and water.  
Buff with a dry clean cloth.





**homestyles** will provide replacements free of charge for missing or damaged parts within 1 year of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **homestyles** is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

**homestyles** Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
[servicedesk@homestylesfurniture.com](mailto:servicedesk@homestylesfurniture.com), 888-680-7460


**IMPORTANT**

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

**Part List**

F.  
Seat Cushion  
1 pc.



G.  
Back Cushion  
1 pc.

**Care Instructions**



- Keep cushions free of natural debris.
- Tip and angle cushions after use.
- Store cushions inside when not in use.
- Allow a minimum of 24 hours for wet cushions to air dry.
- Never use a hairdryer on cushions.
- Never put cushions in a clothes dryer.

For assembly see instructions in carton 6800-57, 6800-58, 6800-101 or 6800-402.


**IMPORTANT**

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

**Part List**

F.  
Seat Cushion  
3 pcs.



G.  
Back Cushion  
3 pcs.

**Care Instructions**

- Keep cushions free of natural debris.
- Tip and angle cushions after use.
- Store cushions inside when not in use.
- Allow a minimum of 24 hours for wet cushions to air dry.
- Never use a hairdryer on cushions.
- Never put cushions in a clothes dryer.

For assembly see instructions in carton 6800-402.