

FINISH® JET-DRY®

Rinse Agent

Finish® Jet-Dry® Rinse Aid has 5x Power Actions and a Glass Protection ingredient for shinier & drier dishes vs. detergent alone. For optimal results, use with your detergents. Experience shiny dishes and spot & film protection (vs. dishwasher detergent alone) with our Finish® Jet Dry® Dishwasher Rinse Aid. It works with your dishwashing detergent to rinse away stubborn leftover food, spots, and film for sparkling dishes, glasses and utensils. Simply fill your rinse aid dispenser with Finish® Jet-Dry® Rinse Aid and it will be automatically released in the rinse cycle every time your dishwasher runs.

Features & Benefits

- 100% better drying vs detergent alone
- Removes spots & residue for brilliant shine
- Easy to use!





<u>finish</u>

FINISH® JET-DRY®

Rinse Agent

Use Instructions

• Check whether your dishwasher has a built-in liquid rinse aid dispenser, which is usually located near the detergent cup(s). Fill your rinse aid dispenser with Finish® Jet-Dry®.

Technical data	FINISH® JET-DRY® Rinse Agent
Color/Form	Blue, Liquid
рН	2.8 to 3.2
Shelf Life	2 Years

Product	Pack size	Dilution	Product code	
FINISH® JET-DRY® Rinse Agent - Original	6 x 16 oz. Squeeze Bottles	Ready-to-use	CB788269	=
FINISH® JET-DRY® Rinse Agent - Original	8 x 8.45 oz. Squeeze Bottles	Ready-to-use	CB757138	-

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, http://naextranet.diversey.com/dot/, for up-to-date shipping information.