
# **CHATEAU**


- Please check your product packaging to make sure the included accessories are in the "list of standard accessories". If any parts are missing, please contact your local dealer immediately.
- Do not allow any sharp objects to come in contact with the cabinet, as it will scratch the surface.
- Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.
- Do not put any hot appliances directly on or near the cabinet.
- •Please avoid using cleaning products that contain bleach or ammonia.
- Wood surfaces should only be cleaned with wood care products such as soapy water or furniture polish.


# ANZZI



NOTE: Mirror(s) not included with all SKU builds. Check listing for details.


# INSTALLATION






## MAIN BODY PARTS








### **INSTALLATION PARTS**
















Tape

Pencil


Impact Drill

Levelling Instrument


Screw driver


Glass Glue Gun


#### INSTALL, REMOVE, ADJUST OF TOP FAST LOADING HINGE











install

remove


adjust the height

adjust the lateral


adjust the deep

#### DRAWER ASSEMBLY AND REMOVAL(WITH PEG)






Pull out the drawer member of the slide from the cabinet, lay the drawer onto the slide.



For removal, pull out the locking pin from the drawer side. Lift the drawer and pull it out from the cabinet.



#### INSTALLATION INSTRUCTIONS

