



# APP USER GUIDE

## Smart Chasing Neon Flex



Feit Electric App

**24/7 HELP** For 24/7 customer support, visit [feit.com/help](http://feit.com/help)

**System Requirements**  
Minimum: iOS 11.0, Android™ 6.0 Marshmallow or higher  
- Dedicated 2.4GHz Wi-Fi Network -

Your screen images may differ from this user guide.

### BEFORE USING THIS USER GUIDE SEE INCLUDED INSTALLATION GUIDE FOR PROPER PRODUCT INSTALLATION.



NOTE: Only works with 2.4GHz Wi-Fi networks.

Go to your Wi-Fi settings and connect your phone to your 2.4GHz Wi-Fi network.



### Set Up Device

- 1 Download the **Feit Electric** app.
- 2 Launch the **Feit Electric** app. Enter an email address to register, then tap **Continue**. A verification code will be sent to your email.
- 3 Create a password then tap **Done**.




### Permissions & Location Access

- 4 **Allow notifications** (highly recommended).
- 5 **Allow the Feit Electric** app to access your location to help connect your String Lights.




### Enable Bluetooth on your smart device to facilitate simple pairing.

- 6 **Enable Bluetooth** on your smart device to facilitate simple pairing.



### Simple Pairing Mode


- 1 Make sure the Chasing Neon Flex Light is flashing red, then tap **Add Device** or the plus icon (+) on the upper right corner.



NOTE: If your Neon Flex light is not flashing red, then press and hold the power button for 5 seconds or until the unit starts to flash red.


### Simple Pairing Mode

- 2 The Chasing Neon Flex Light name(s) will appear in a small window for simple pairing enabled devices. Tap **Go to add**.
- 3 Select one Chasing Neon Flex Light from the list. Tap the plus icon (+).



### Simple Pairing Mode


- 4 After confirming that you are on a 2.4GHz Wi-Fi network, enter your password then tap **Confirm**.



### Simple Pairing Mode

- 5 The status window will appear and show progress toward set-up.
- 6 To rename press next, tap the **Pen** icon, enter the new name and tap **Done**. The Chasing Neon Flex Light is now ready to be controlled with the **Feit Electric** app.


NOTE: If unsuccessful, the **Failed to Add** screen will appear. Quit the app and repeat the previous steps.



NOTE: Constant power to the Chasing Neon Flex Light is required at all times.

### Alternative Set-up Method EZ Mode

- 1 Tap the plus icon (+) in the upper right corner.




NOTE: Use **EZ Mode** to set up multiple smart products at the same time or if there are issues with simple pairing.

- 2 Tap **Lighting**, then select **Chasing Neon Flex Light**.




- 3 Tap the upper right corner and make sure you have **EZ Mode** selected. Follow steps 4-6 from **Simple Pairing Mode** to complete setup.



### Alternative Set-up Method AP Mode

- 1 Tap the plus icon (+) in the upper right corner.
- NOTE: AP Mode is an alternative method to connect your device if **Simple Pairing Mode** and **EZ Mode** are not successful.
- 2 Tap **Lighting**, then select **Chasing Neon Flex Light**.




- 3 Choose **AP Mode**. Make sure your Chasing Neon Flex Light is in AP pairing mode (light should flash one time every two seconds). Tap **Confirm** then tap **Next** to go on to the next step.
- NOTE: If the Chasing Neon Flex Light is already flashing red, then, hold the control module power button again for another 5 seconds to enter in **AP mode**. It will blink slower.



NOTE: If the Chasing Neon Flex Light is already flashing red, then, hold the control module power button again for another 5 seconds to enter in AP mode. It will blink slower.

- 4 Enter the name of your 2.4GHz Wi-Fi network, enter your password and tap **Next** to begin connecting.
- NOTE: Your Wi-Fi network name and password are case sensitive.



NOTE: Your Wi-Fi network name and password are case sensitive.

- 5 Tap **Go connect**. In your smart device's Wi-Fi settings, choose the **SmartLife-XXXX** network.
  - 6 In your smart device's Wi-Fi settings, choose the **SmartLife-XXXX** network. After you have connected to **SmartLife**, return to the **Feit Electric** app.
- NOTE: After connecting the Chasing Neon Flex Light, your smart device will automatically rejoin your original 2.4GHz network.



NOTE: After connecting the Chasing Neon Flex Light, your smart device will automatically rejoin your original 2.4GHz network.

- 7 Your device should begin connecting using **AP Mode**.
- 8 If you see this screen your device was added successfully.



### Features

- 1 **Individual Chasing Neon Flex Light On/Off**  
Tap the Chasing Neon Flex Light icon to turn the Neon Flex On/Off.
- 2 **Individual Chasing Neon Flex Light Operation**  
Press and hold the Chasing Neon Flex Light icon for two seconds to enter operation.




### Dimming

- 3 Tap and hold the **Dimming** bar at the bottom of the screen. Slide the dimming bar left or right to set the brightness level. Tabs above the dimmer bar allow you to choose desired colors or color combinations.



### Custom Color Changing

- 4 Tap the **Squiggly line** icon as shown below on your screen. Tap your desired color. Then tap the Chasing Neon Flex Light sections to fill in with your desired color.
- 5 Tap the **Button** icon to create a seamless color blend.




- 6 Tap the **Eraser** icon as shown below on your screen. Tap the Chasing Neon Flex Light sections that you would like to change. The color will disappear from those sections after you tap them.



### Music

- 5 Tap the **Music** icon to sync your light with the rhythm of music. Tap **Local Mode** to sync your light to your music without remaining on the app. Tap **App Mode** to sync your light to music only when the app is open.




### Scene

- 6 Tap the **Color** icon in the bottom of the screen. Tap the desired Scene from the middle of your screen.



### Modify

- 7 Tap the **Add +** button from the top right. Choose a Scene style option from the top of your screen. Tap **New Scene** (1) to name your scene, then tap **Confirm**. Tap **Preview** (2) to view the effect on your Chasing Neon Flex Light. Tap **Save** (3) to lock in desired effect.
- A There are up to 16 **scene** styles to choose from.
- B Customize your color options using the color bar.



### Plan

- 8 Tap the **Other** icon in the bottom right of your screen.
- 9 Tap **Plan**.
- 10 Tap the **Countdown** toggle button.
- 11 Set the countdown to turn the light off by scrolling up or down on the **Hour**, **Minute** and **Second**. Tap **Save** in the upper right hand corner once you have set your desired time.



### Chasing Neon Flex Light Length

- 9 If you'd like to adjust how much of the neon flex you'd like to animate drag the slider right for a max of 3m and minimum of 1.5m.



### Groups

- 1 Tap the **Groups** icon at the bottom of the app home screen.
  - 2 Tap on **Create Group**.
  - 3 Tap on **Chasing Neon Flex Light**.
- NOTE: To create groups you will need at least two Chasing Neon Flex Lights. You can only group a Chasing Neon Flex Light with other Chasing Neon Flex Lights.



### Groups

- 4 Select the Chasing Neon Flex Lights that you want to group.
- 5 Tap the group name and enter the name of the group.




### Groups

- 6 Once the group is named and the Chasing Neon Flex Lights are selected, tap **Save** in the upper right corner.




### Manage Groups

- 7 Tap the **Groups** icon.
- 8 Tap the context menu in the upper right corner (☰).
- 9 Tap **Manage Group**.



### Manage Groups

- 10 Select the group to edit.
- 11 Once selected, tap **Edit** in the upper right hand corner.
- 12 Rename the group or remove a Chasing Neon Flex Light from the group. Once complete, tap **Save** in the upper right corner.



### 13 Delete Groups

Tap the **Groups** icon.

14 Tap the context menu in the upper right corner (•••).

15 Tap **Delete Group**.

### 16 Select the group to delete.

Select the group to delete. Once selected, tap **Delete Group** in the upper right corner.

17 Tap **Confirm**.

### Share Control of a Device (Two Methods)

1 **Method 1:** Tap the **Profile** icon, then tap **Share Devices**.

A **Method 2:** From the Chasing Neon Flex Light's settings menu, tap the **Pen** icon located in the upper right corner. Then tap **Share Devices**.

2 Tap **Add** at the bottom of the screen.

3 Select the device that you wish to share. Tap **Sharing** in the upper right corner.

4 Enter the account name of the person you want to share with with (this is typically their email address). Then tap **Done** when prompted.

**NOTE:** New members must set up an account before sharing is possible.

### Share Control of All Devices Within a Location

1 From the home screen, tap **Profile**, then **Location Management**, then the location you would like to share. Tap **Add members**.

2 Enter the new member's email address then tap **Add**.

### Room Management

1 Tap the three dots from the home menu, then tap **Room Management**.

2 Tap **Add a Room**.

3 Tap on a preset room name or create your own.

4 Add individual lamps by tapping on the icon (+) next to each Chasing Neon Flex Light's name.

5 When finished, tap **Save** in the upper right corner.

6 Remove individual Chasing Neon Flex Lights by tapping on the icon (-) next to each Chasing Strip Light's name.

### Home Management

1 Tap **Home** from the main menu, then tap **Location Management**.

2 Tap **Add Location** to indicate where the bulbs are located.

### Smart Scenes

1 From the **My Home** page, tap **Smart Scenes** at the bottom of screen.

**NOTE:** Use **Smart Scenes** to set up an action or group of actions.

2 In the **Smart Scenes** tab, tap the plus icon (+).

3 Tap on **Launch Scenes**.

4 Tap on **Run the device**.

5 Select your device to initiate an action.

6 On the **Select Function** screen, tap on the action you want the device to perform.

A On the Switch screen, tap On or Off.

7 Review your scene, edit them if necessary, then **Save**.

8 Your action(s) will appear under **Scene** tab.

A It will also appear on the top of your **My Home** screen. Tap to execute our action(s).

### Automation

1 From the **My Home** page, tap **Smart Scenes** at the bottom of screen.

2 Tap **Automation** at the top of the screen, and then tap on plus icon (+).

3 Set a **condition** you would like to trigger.

**NOTE:** Use **Automation** to initiate an action based on certain conditions (Sunrise/Sunset, Location Change, Schedule, Device Status, etc.).

4 Set up a **task** you would like to automate.

5 Review your automations, edit them if necessary, then **Save**.

6 Your automation will appear under the **Automation** tab.

### Enable Siri Shortcuts® (for use with iPhone)

1 From the **My Home** page, tap **Smart Scenes** at the bottom of screen.

**NOTE:** Use **Siri** to activate a scene through voice control. If you have not created a scene, see the **Smart Scenes** section.

2 In the **Scene** tab, tap **Add to Siri** located at the bottom of the screen.

3 In the **Siri Shortcut** screen, tap on the action you would like to add to **Siri**.

4 On the **"Hey Siri"** screen, tap on the device name to edit it. Tap **Done** at the bottom of the screen.

5 Now you can use the **"Hey Siri"** command to control this action from your iOS device. **"Hey Siri, turn on Chasing Neon Flex Light!"**

### CONNECT TO ALEXA

1 Tap on **Profile** at bottom right. Tap on **Use Alexa and Google Assistant**.

**NOTE:** Sign in to Amazon Alexa. If you do not have an account with Amazon, please create one.

2 Tap on **Amazon Alexa**.

3 Tap on **Link with Amazon Alexa**.

4 Tap on **Link**. You will be linked automatically to your Amazon Alexa app.

**NOTE:** Additional devices will be added automatically when added to the **Feit Electric** app.

### CONNECT TO GOOGLE ASSISTANT

1 Tap on **Profile** bottom right. Tap on **Use Alexa and Google Assistant**.

**NOTE:** Sign in to Google Assistant. If you do not have an account with Google, please create one.

2 Tap on **Google Assistant**.

3 Tap on **Link with Google Assistant**.

4 Tap on **Link**. You will be linked automatically to your Google Assistant app.

**NOTE:** Additional devices will be added automatically when added to the **Feit Electric** app.

## Need Help?

Please refer to our online resources at [www.feit.com/help](http://www.feit.com/help) to learn about more features & latest updates

24/7 HELP [feit.com/help](http://feit.com/help)